




**Register** your  
new device on  
MyBosch now and  
get free benefits:  
**[bosch-home.com/  
welcome](https://bosch-home.com/welcome)**



# Free standing cooker

**HSB738357M**

**en** Instruction manual  
**ar** دليل الاستعمال

3  
3



# Table of contents

|                                                                                    |                                                       |    |
|------------------------------------------------------------------------------------|-------------------------------------------------------|----|
|    | <b>Intended use</b> .....                             | 4  |
|    | <b>Important safety information</b> .....             | 4  |
|                                                                                    | General information .....                             | 5  |
|    | <b>Causes of damage</b> .....                         | 7  |
|                                                                                    | Hob .....                                             | 7  |
|                                                                                    | Oven .....                                            | 7  |
|    | <b>Environmental protection</b> .....                 | 8  |
|                                                                                    | Saving energy with your oven .....                    | 8  |
|                                                                                    | Saving energy with the hob .....                      | 8  |
|                                                                                    | Environmentally-friendly disposal .....               | 8  |
|    | <b>Getting to know your appliance</b> .....           | 8  |
|                                                                                    | The control panel .....                               | 9  |
|                                                                                    | The electronic clock .....                            | 9  |
|                                                                                    | The hob .....                                         | 9  |
|                                                                                    | The oven .....                                        | 10 |
|                                                                                    | Cooling fan .....                                     | 11 |
|                                                                                    | The storage compartment .....                         | 11 |
|   | <b>Accessories</b> .....                              | 11 |
|                                                                                    | Locking function .....                                | 12 |
|                                                                                    | Special accessories .....                             | 12 |
|  | <b>Before using for the first time</b> .....          | 13 |
|                                                                                    | Setting the time .....                                | 13 |
|                                                                                    | Baking out the oven .....                             | 13 |
|                                                                                    | Cleaning the burner caps and cups .....               | 13 |
|                                                                                    | Cleaning the accessories .....                        | 13 |
|                                                                                    | Fitting the threaded bushes for the rotary spit ..... | 13 |
|                                                                                    | Fitting the telescopic shelf set .....                | 13 |
|  | <b>Operating the appliance</b> .....                  | 13 |
|                                                                                    | Hob .....                                             | 13 |
|                                                                                    | Oven .....                                            | 14 |
|                                                                                    | Rotary spit .....                                     | 14 |
|  | <b>Time-setting options</b> .....                     | 15 |
|  | <b>Cleaning agent</b> .....                           | 16 |
|                                                                                    | Suitable cleaning agents .....                        | 16 |
|                                                                                    | Surfaces in the cooking compartment .....             | 17 |
|                                                                                    | Keeping the appliance clean .....                     | 18 |
|                                                                                    | Cleaning the cooking compartment .....                | 18 |
|  | <b>Rails</b> .....                                    | 18 |
|                                                                                    | Removing the hook-in racks .....                      | 18 |
|                                                                                    | Inserting the hook-in rack .....                      | 18 |
|  | <b>Appliance door</b> .....                           | 19 |
|                                                                                    | Removing and installing the door panels .....         | 19 |
|                                                                                    | Removing and fitting the appliance door .....         | 19 |

|                                                                                   |                                                   |    |
|-----------------------------------------------------------------------------------|---------------------------------------------------|----|
|  | <b>Trouble shooting</b> .....                     | 21 |
|                                                                                   | Replacing the oven light bulb .....               | 21 |
|  | <b>Customer service</b> .....                     | 22 |
|  | <b>Tested for you in our cooking studio</b> ..... | 23 |
|                                                                                   | Table of dishes .....                             | 23 |
|                                                                                   | Tips for using your appliance .....               | 24 |

---

Additional information on products, accessories, replacement parts and services can be found at **[www.bosch-home.com](http://www.bosch-home.com)** and in the online shop **[www.bosch-eshop.com](http://www.bosch-eshop.com)**

## Intended use

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual and installation instructions for future use or for subsequent owners.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The appliance must be supervised during operation. Only use this appliance indoors.

This appliance is intended for use up to a maximum height of 2000 metres above sea level.

This appliance is not intended for operation with an external clock timer or a remote control.

Do not use inappropriate child safety shields or hob guards. These can cause accidents.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 15 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always slide accessories into the cooking compartment the right way round.

→ "Accessories" on page 11

Close the safety valve on the gas supply line if the cooker will not be used for a prolonged period.

## Important safety information

### **Warning – WHAT TO DO IF YOU SMELL GAS!**

Escaping gas may cause an explosion.

#### **If you smell gas or notice any faults in the gas installation:**

- Immediately shut off the gas supply or close the gas cylinder valve.
- Immediately extinguish all naked flames and cigarettes.
- Do not use any light or appliance switches and do not pull any plugs out of sockets. Do not use any telephones or mobile phones within the building.
- Open windows and ventilate the room.
- Call the after-sales service or the gas supplier.

### **Warning – Risk of asphyxiation!**

The use of a gas cooker leads to a build-up of heat, moisture and products of combustion in the room where the appliance is installed. Ensure that the installation room is well ventilated. The natural ventilation openings must be kept open or a mechanical ventilation device must be provided (e.g. an extractor hood). Intensive and persistent use of the appliance may mean that it is necessary to have additional ventilation (e.g. opening a window), or more effective ventilation (e.g. operating the existing mechanical ventilation device at a higher setting).

## General information

### **Warning – Risk of fire!**

- A draught is created when the appliance door is opened. Greaseproof paper may come into contact with the heating element and catch fire. Do not place greaseproof paper loosely over accessories during preheating. Always weight down the greaseproof paper with a dish or a baking tin. Only cover the surface required with greaseproof paper. Greaseproof paper must not protrude over the accessories.
- Combustible objects that are left in the cooking compartment may ignite. Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance and unplug the mains plug or switch off the fuse in the fuse box. Shut off the gas supply.
- Hot oil and fat can ignite very quickly. Never leave hot fat or oil unattended. Never use water to put out burning oil or fat. Switch off the hotplate. Extinguish flames carefully using a lid, fire blanket or something similar.
- The hotplates become very hot. Never place combustible items on the hob. Never place objects on the hob.
- The appliance becomes very hot and flammable materials could catch fire. Never store or use flammable objects (e.g. spray cans, cleaning agents) under the appliance or in its immediate vicinity. Never place flammable items on or in the appliance.
- When gas hotplates are in operation without any cookware placed on them, they can build up a lot of heat. The appliance and the extractor hood above it may become damaged or be set on fire. Grease residue in the filter of the extractor hood may ignite. Only operate the gas burners with cookware on them.
- The rear of the appliance becomes very hot. This may cause damage to the power cables. Electricity and gas lines must not come into contact with the rear of the appliance.

### **Warning – Risk of burns!**

- The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.
- Accessories and ovenware become very hot. Always use oven gloves to remove accessories or ovenware from the cooking compartment.
- Alcoholic vapours may catch fire in the hot cooking compartment. Never prepare food containing large quantities of drinks with a high alcohol content. Only use small quantities of drinks with a high alcohol content. Open the appliance door with care.
- The hotplates and surrounding area (particularly the hob surround, if fitted) become very hot. Never touch the hot surfaces. Keep children at a safe distance.
- The accessible parts become very hot when in operation. Never touch hot parts. Keep children at a safe distance.
- Empty cookware becomes extremely hot when set on a gas hotplate that is in operation. Never heat up empty cookware.

### **Warning – Risk of scalding!**


- The accessible parts become hot during operation. Never touch the hot parts. Keep children at a safe distance.
- When you open the appliance door, hot steam may escape. Open the appliance door with care. Keep children at a safe distance.
- Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.

**⚠ Warning – Risk of injury!**

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- Incorrect repairs are dangerous. Repairs may only be carried out, and damaged power and gas lines replaced, by an after-sales engineer trained by us. If the appliance is faulty, unplug the mains plug or switch off the fuse in the fuse box. Shut off the gas supply. Contact the after-sales service.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.
- Faults or damage to the appliance are dangerous. Never switch on a faulty appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Shut off the gas supply. Contact the after-sales service.
- Unsuitable pan sizes, damaged or incorrectly positioned pans can cause serious injury. Observe the instructions which accompany the cookware.
- If the appliance is placed on a base and is not secured, it may slide off the base. The appliance must be fixed to the base.
- **Caution:** Glass lids may shatter when heated. Turn off all the burners before shutting the lid. Wait until the oven has cooled down before closing the glass cover.  
Before opening the top cover, remove any spills with a cloth.



**⚠ Warning – Risk of tipping!**



**Warning:** In order to prevent tipping of the appliance, this stabilizing means must be installed. Refer to the instructions for installation.

**⚠ Warning – Risk of electric shock!**

- Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.
- When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

**⚠ Warning – Hazard due to magnetism!**

Permanent magnets are used in the control panel or in the control elements. They may affect electronic implants, e.g. heart pacemakers or insulin pumps. Wearers of electronic implants must stay at least 10 cm away from the control panel.

**⚠ Warning – Risk of overheating!**

Covering the ventilation openings in the floor of the appliance may cause it to overheat. Always install the appliance on the feet supplied.

## Causes of damage

### Hob

#### Caution!

- Only use the burners when cookware has been placed on top. Do not heat up empty pots or pans. The saucepan base will be damaged.
- Clear up spills immediately. Use deep pots for dishes with a lot of liquid. This will prevent the food from boiling over.
- Do not use roasting dishes if they must be heated using two burners. This will cause heat accumulation. The appliance could be damaged.
- Cooking on gas burners releases extra heat and moisture. Adjacent units may become damaged over time. For long cooking times, switch on the cooker hood or ventilate the room.
- Observe the manufacturer's instructions when using special ovenware. Aluminium foil and plastic containers can melt and stick on hot burners.
- Place the pot or pan centrally over the burner. This will optimise transfer of the heat from the burner flame to the pot or pan base. The handle does not become damaged, and greater energy savings are guaranteed.
- Ensure that the gas burners are clean and dry. The burner cup and burner cap must be positioned exactly.
- Ensure that the hotplate/burner is never switched on when the hob cover is on, e.g. by children playing.

### Oven

#### Caution!

- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. Do not place ovenware on the cooking compartment floor. This will cause heat accumulation. The baking and roasting times will no longer be correct and the enamel will be damaged.
- Inserting accessories: depending on the appliance model, accessories can scratch the door panel when closing the appliance door. Always insert the accessories into the cooking compartment as far as they will go.
- Water in a hot cooking compartment: do not pour water into the cooking compartment when it is hot. This will cause steam. The temperature change can cause damage to the enamel.
- Moist food: do not store moist food in the cooking compartment when it is closed for prolonged periods. This will damage the enamel.
- Fruit juice: when baking particularly juicy fruit pies, do not pack the baking tray too generously. Fruit juice dripping from the baking tray leaves stains that cannot be removed. If possible, use the deeper universal pan.
- Cooling with the appliance door open: only allow the cooking compartment to cool when it is closed. Even if the appliance door is only open a little, front panels of adjacent units could be damaged over time.
- Heavily soiled oven seal: if the oven seal is heavily soiled, the oven door will no longer close properly when the oven is in operation. The fronts of adjacent units could be damaged. Always keep the oven seal clean.
- Oven door as a bearing surface: do not stand or place objects on the oven door when it is open. Do not hang objects on the oven door.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.
- Heavy accessories: do not pull out heavily laden accessories too far without first unloading them sufficiently. Heavy accessories will tip when pulled out. This causes pressure to be exerted on the shelf supports in the cooking compartment, which can damage the enamel. Relieve the strain on the accessories when they are pulled out by raising them slightly with one hand. Caution: always use an oven cloth or oven gloves when handling hot accessories.

## Environmental protection

Your new appliance is particularly energy-efficient. Here you can find tips on how to save even more energy when using the appliance, and how to dispose of your appliance properly.

### Saving energy with your oven

- Only preheat the oven if this is specified in the recipe or in the operating instruction tables.
- Use dark, black lacquered or enamelled baking tins. They absorb the heat particularly well.
- Open the oven door as infrequently as possible while cooking, baking or roasting.
- It is best to bake more than one cake, one after the other. The oven is still warm. This reduces the baking time for the second cake. You can also place two loaf tins next to each other.
- For longer cooking times, you can switch the oven off 10 minutes before the end of the cooking time and use the residual heat to finish cooking.

### Saving energy with the hob

- Always use a saucepan which is the correct size for your food. A larger, less full saucepan requires a lot of energy.
- Always place a suitable lid on the saucepan.
- Switch to a lower heat setting in good time.
- The gas flame must always be in contact with the base of the saucepan.

### Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.




This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

## Getting to know your appliance


Use this section to familiarise yourself with your new appliance. You will find information about the control panel and hob, as well as the oven, types of heating and accessories.

Depending on the appliance model, individual details may differ.



| Explanation |                     |
|-------------|---------------------|
| 1           | Hob cover           |
| 2           | Hob                 |
| 3           | Control panel       |
| 4           | Oven                |
| 5           | Storage compartment |

## The control panel



### Explanation

|   |                                   |
|---|-----------------------------------|
| 1 | Electronic clock                  |
| 2 | Control knob for oven temperature |
| 3 | Oven indicator light              |
| 4 | Control knob for oven functions   |
| 5 | Control knob for hotplates        |

## The electronic clock

With the electronic clock, you can set a cooking time. An audible signal sounds once the cooking time has elapsed.

### Function buttons for the electronic clock


| Symbol | Meaning          | Use                                    |
|--------|------------------|----------------------------------------|
| ⌚      | Electronic clock | Sets the cooking time or the time      |
| -      | Minus            | Reduces the cooking time or the time   |
| +      | Plus             | Increases the cooking time or the time |

## The hob

### ⚠ Warning – Risk of burns!

Hot air flows out from the ventilation opening on the hob. Never touch the ventilation opening.

Please note that, in the case of appliances with a hob cover, the burners in the oven must also only be switched on if the hob cover is open.



### Explanation


|   |                             |
|---|-----------------------------|
| 1 | High-output burner (2.9 kW) |
| 2 | Wok burner (4 kW)           |
| 3 | Standard burner (1.8 kW)    |
| 4 | Ventilation opening         |
| 5 | Economy burner (1.0 kW)     |

## Types of gas burner


| Gas burners        | Pot/pan diameter |
|--------------------|------------------|
| Economy burner     | 12 - 14 cm       |
| Standard burner    | 16 - 22 cm       |
| High output burner | 18 - 26 cm       |
| Wok burner         | 18 - 26 cm       |

## Precautions for use


The following advice is intended to help you save energy and prevent pan damage:




Use pans which are the right size for each burner. Do not use small pans on large burners. The flame must not touch the sides of the pan.




Do not use damaged pans, which do not sit evenly on the hob. Pans may tip over. Only use pans with a thick, flat base.



Do not cook without using a lid and make sure the lid is properly fitted. This wastes energy.




Always centre the pan over the burner, not to one side. Otherwise it could tip over. Do not place large pans on the burners near the control knobs. These may be damaged by the very high temperatures.




Place the pans on the pan supports, never directly on the burner.

Make sure that the pan supports and burner caps are correctly positioned before using the appliance.



Pans should be placed on the hob carefully. Do not strike the hob and do not place excessive weight on it.



Never use two burners or heat sources to heat one single pan. Do not use grill pans, earthenware casserole dishes, etc. for a long period of time on maximum power.

## Control knob for hotplates

This control knob is used to adjust the heat setting of the gas burner hotplates.

The symbols above the control knob show you the gas burner to which the control knob belongs.

| Setting | Meaning                     |
|---------|-----------------------------|
| o       | Off                         |
|         | Large flame, highest power  |
|         | Economy flame, lowest power |

## The oven

In order to operate the oven, you require two operating knobs: The function selector and the temperature selector.

### Control knob for oven

#### Function selector

Use the function selector to set the type of heating.

| Type of heating            | Use                                                                                                                                                                                      |
|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Hot air                    | For baking and cooking on one or more levels.<br>The fan distributes the heat from the ring heating element in the back panel evenly around the cooking compartment.                     |
| Eco                        | For energy-optimised cooking of selected dishes.<br>Heat is emitted evenly from the top and bottom.                                                                                      |
| Top/bottom heating and fan | For cakes with very moist toppings.<br>Heat is emitted evenly from the top and bottom. The fan circulates the hot air around the food.                                                   |
| Top/bottom heating         | For traditional baking and roasting on one level. Especially suitable for cakes with moist toppings.<br>Heat is emitted evenly from the top and bottom.                                  |
| Bottom heating and fan     | For the final baking stage (such as for moist fruit flans), for boiling down, for dishes in a bain marie.<br>Heat is emitted from below. The fan circulates the hot air around the food. |
| Hot air grill              | For roasting poultry, whole fish and larger pieces of meat.<br>The whole area below the grill element becomes hot. The fan circulates the hot air around the food.                       |
| Full-surface grill         | For grilling flat items, such as steaks or sausages, for making toast, and for au gratin dishes.<br>The whole area below the grill element becomes hot.                                  |
| Grill/rotary spit          | Grill: For individual portions or smaller quantities of steaks, sausages, fish and toast.<br>Rotary spit: For roasts, rolled joints and poultry                                          |

## Temperature selector

You can use the temperature selector to set the temperature.

| Setting  | Meaning                 |
|----------|-------------------------|
| o        | Off                     |
| 50 - 260 | Temperature range in °C |

There is a limit stop between positions 260 and o. Do not turn the knob beyond this point.

**Note:** To defrost: Set the function selector to  and the temperature selector to o.


## Cooling fan

The hot air escapes via the ventilation opening. The cooling fan switches on and off as required. Caution. Do not cover the ventilation slots. Otherwise the oven will overheat.

To ensure that the cooking compartment cools down more quickly after operation, the cooling fan continues to run for a certain period afterwards.

## The storage compartment

Open the storage compartment by folding down the fascia panel.




This compartment can be used to store hob or oven accessories.

### **Warning – Risk of fire!**


Never leave combustible items in the storage compartment.

## Accessories

Your appliance is accompanied by a range of accessories. Here, you can find an overview of the accessories included and information on how to use them correctly.


| Accessories                                                                          | Description                                                                                                                                                                            |
|--------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <b>Baking and roasting shelf</b><br>For ovenware, cake tins, joints, grilled items, frozen meals.                                                                                      |
|    | <b>Universal pan</b><br>For moist cakes, pastries, frozen meals and large roasts. The universal pan can be used to catch dripping fat when you are grilling directly on the wire rack. |
|    | <b>Espresso attachment</b><br>Attachment for an espresso pot; for placing on the economy burner.                                                                                       |
|    | <b>Rotary spit</b><br>With rotary spit holder<br>For roasting joints and large poultry. Only use in combination with a universal pan.                                                  |
|   | <b>Locking pins</b><br>For locking the hinges.                                                                                                                                         |
|  | <b>Telescopic shelf set</b><br>The pull-out rails allow you to pull accessories out completely.                                                                                        |

The baking tray and the baking and roasting shelf can be moved into five different heights within the cooking compartment. Always insert them as far as they will go so that the accessories do not touch the door panel. Ensure that you always insert the accessories into the cooking compartment the right way round.



### Telescopic shelf set

The pull-out rails allow you to pull accessories out completely. When inserting the adapter for the baking and roasting shelf, ensure that it locks into place in front of the indentation on the pull-out rails.



**Note:** The rotary spit must be inserted on level 1. In this case, move the pull-out rails for the baking tray and the baking and roasting shelf to the four upper levels.


### ⚠ Warning – Risk of fire!

Under no circumstances should a roasting tin, baking tray, frying pan or any other form of cookware be placed directly on the oven floor. This causes the floor of the appliance to overheat and can seriously damage the appliance.

### Locking function


The accessories can be pulled out approximately halfway until they lock in place. The locking function prevents the accessories from tilting when they are pulled out. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.

When inserting the wire rack, ensure that the lug **a** is at the rear and is facing downwards. The open side must be facing the appliance door and the outer rail must be facing downwards.



When inserting baking trays, ensure that lug **a** is at the rear and is facing downwards. The sloping edge of the accessory **b** must be facing towards the appliance door.

Example in the picture: Universal pan



### Special accessories

You can buy accessories from the after-sales service.

| Accessories                      | Description                                                                                                                                                                                                                                                          |
|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Enamel baking tray</b>        | For tray bakes and small baked products.<br>Customer service number: 11012235                                                                                                                                                                                        |
| <b>Universal pan</b>             | For moist cakes, pastries, frozen meals and large roasts.<br>The universal pan can be used to catch dripping fat when you are grilling directly on the wire rack.<br>After-sales service number: 11012236                                                            |
| <b>Baking and roasting shelf</b> | For ovenware, cake tins, joints, grilled items, frozen meals.<br>After-sales service number: 11012237                                                                                                                                                                |
| <b>Wok ring</b>                  | Attachment for a wok; for placing on the wok burner.<br>When using the wok attachment, it is possible to use cooking vessels with a diameter greater than 26 cm (woks, frying pans, pots, vessels with a curved base, etc.).<br>After-sales service number: 00745721 |
| <b>Telescopic shelf set</b>      | Telescopic shelf set for one level.<br>After-sales service number: 12006236                                                                                                                                                                                          |
| <b>Pressure regulator</b>        | Pressure regulator for liquefied gas mode.<br>For Oman: Bottle connecting nut size 27 mm (height 14 mm) – inner support 12.5 mm<br>After-sales service number: 752313                                                                                                |
| <b>Pressure regulator</b>        | Pressure regulator for liquefied gas mode.<br>For UAE/Yemen: Bottle connecting nut size 25 mm (height 16 mm) – inner support 10 mm<br>After-sales service number: 618228                                                                                             |



### Before using for the first time

In this section, you can find out what you must do before using your oven or hob to prepare food for the first time. Read the following section beforehand.

→ "Important safety information" on page 4

Remove the appliance packaging and dispose of it appropriately.

## Setting the time

**Note:** If the time is not set, the oven will not switch on.

On the first use, or after a power failure, the digits and  flash on the display.

1. Press  for 2 seconds.  
The dot between the hours and the minutes flashes.
2. Use the + or - button to set the clock.  
**Note:** Keep the button pressed in to increase or decrease rapidly.
3. Wait 7 seconds.  
The dot between the hours and the minutes stops flashing. The time that has been set is adopted.

**Note:** To change the set time, press the + and - buttons at the same time for two seconds, then set the current time with the + and - buttons.

## Baking out the oven

### Precleaning the oven

1. Remove accessories and hook-in racks from the cooking compartment.
2. Fully remove any remaining packaging, such as small pieces of polystyrene, from the cooking compartment.
3. Some parts are covered with a protective film. Remove the protective film.
- 4.
5. Clean the cooking compartment with hot soapy water. Clean the outside of the appliance with a soft, damp cloth.

### Heating up the oven


To remove the new cooker smell, heat up the oven when it is empty and closed.

1. Turn the temperature selector to the maximum temperature.
2. Switch off the oven after 45 minutes.

### Recleaning the oven

1. Clean the cooking compartment with hot soapy water.
2. Fit the hook-in racks.

## Cleaning the burner caps and cups




1. Clean the burner caps (A) and cups (B) with water and washing-up liquid.
2. Dry the parts well.
3. Place the burner cup (B) onto the burner (C).
4. Position the burner cap (A) exactly on the burner cup (B).

## Cleaning the accessories

Before using the accessories, clean them thoroughly using a cloth and warm soapy water.

### Fitting the threaded bushes for the rotary spit

1. From above, place the threaded bushes into the holes at the four corners of the universal pan.
2. Counter the ring nuts from below.
3. Use a screwdriver to tighten the threaded bushes.



### Fitting the telescopic shelf set

Instructions on fitting the telescopic shelf set are enclosed with the set.



## Operating the appliance

You have already learnt about the controls and how they work. Now we will explain how to set your appliance. You will learn about what happens when you switch the appliance on and off, and how to select the operating mode.

## Hob

### Switching on the gas burner

#### Notes

- Appliances with a hob cover must only be switched on if the hob cover is open.
- The burner caps must always be positioned exactly on top of the burner cups. The slots on the burner cup must be free from obstruction. All parts must be dry.
- Ensure that the burner is not subjected to draughts caused by air conditioning systems, fans or similar appliances.

1. Press the control knob for the required burner and turn it to the  position.  
The gas burner ignites.
2. Keep the control knob pressed for a few seconds until the flame stabilises.
3. Set the desired flame setting.

| Setting                                                                             | Meaning                     |
|-------------------------------------------------------------------------------------|-----------------------------|
|  | Economy flame, lowest power |
|  | Large flame, highest power  |

The flame is not stable between positions 0 and ①. Always select a position between ① and ②.

### If the flame goes out

Switch off the control knob. Wait one minute and switch the burner on again.

### ⚠ Warning – Risk of fire!

If the flame goes out, gas will escape. Never leave the gas burner unattended during operation. Ensure that there are no draughts.

### ⚠ Warning – Risk of deflagration!

If the burner does not ignite after 15 seconds, switch off the control knob and open the door or window in the room. Wait at least 1 minute before igniting the burner again.

### If the gas burner does not ignite

In the event of a power cut or damp ignition plugs, light the gas burner with a gas lighter or a match.

### Switching off the gas burner

Turn the control knob for the required hotplate to position 0.

## Oven

### Operating the oven

#### Switching on the oven

**Note:** Always keep the appliance door closed when it is in operation.

1. Turn the function selector to the desired operating mode.
2. Turn the temperature selector to set the desired temperature.  
The oven switches on.

The indicator lamp is lit when the oven is heating up. It goes out during pauses in heating.

**Note:** The indicator lamp also lights up when the function selector is in the off position and a temperature is set. The oven only begins to heat up when an operating mode is set.


#### Switching off the oven

1. Turn the function selector to the 0 position.
2. Turn the temperature selector to the 0 position.  
The oven switches off.


## Rotary spit

### Preparing the rotary spit

1. Slide a retaining clip onto the rotary spit and screw on the handle.



2. Place the roast as close as possible to the centre of the rotary spit.
3. Use retaining clips to secure the roast in place.
4. Use milled screws to secure the retaining clips.




### Inserting the rotary spit


### ⚠ Warning – Risk of burns!

Never touch the hot surfaces of the cooking compartment or the heating elements. Children must be kept at a safe distance from the appliance at all times. Open the appliance door carefully. Hot steam may escape.


1. Insert the rotary spit frame into the threaded bushes



2. Place the rotary spit onto the rotary spit frame and unscrew the handle.



3. Slide the universal pan into shelf position 1 and slide the rotary spit into the motor mount.



4. Close the appliance door.

## Switching on the rotary spit

**Note:** When using the rotary spit, preheat the oven using the  type of heating. Only set the  type of heating once the rotary spit has been inserted.

1. Turn the control knob for the oven to the  position.
2. Set the temperature.

**Note:** Add some water to the universal pan in order to catch any fat that drips out.

## Removing the rotary spit

### **Warning – Risk of burns!**

Never touch the hot surfaces of the cooking compartment or the heating elements. Children must be kept at a safe distance from the appliance at all times. Open the appliance door carefully. Hot steam may escape.

1. Opening the appliance door
2. Slowly pull the universal pan until it is halfway out of the cooking compartment.
3. Completely remove the universal pan from the cooking compartment and set it on the worktop.
4. Screw on the handle and remove the grill spit from the grill spit frame.

## Time-setting options

### Setting the time

**Note:** If the time is not set, the oven will not switch on.

On the first use, or after a power failure, the digits and  flash on the display.

1. Press  for 2 seconds.  
The dot between the hours and the minutes flashes.  
The symbol  is shown fixed above the dot.
2. Use the + or - button to set the clock.  
**Note:** Keep the button pressed in to increase or decrease rapidly.
3. Wait 7 seconds.  
The dot between the hours and the minutes stops flashing. The time that has been set is adopted.

### Notes

- To change the set time, press the + and - buttons at the same time for two seconds, then set the current time with the + and - buttons.
- If the programmer is not in timed cooking or programmed cooking mode, you can use oven functions manually.

### Setting timed cooking

Timed cooking is the function which allows the user to set a duration for the cooking operation. When duration time is passed, the cooking operation is automatically ended.

1. Press  until  appears.
2. Press  again.  
The display will show the digits 0.00 and the text dur in sequence, while A flashes.
3. Use the + or - button to set the required minutes of cooking.

4. Wait 5 seconds without pressing any key in order for the function to activate.  
The current time and A appear on the display.
5. Select a function and a cooking temperature.
6. When cooking is completed, an audible signal (buzzer) will be heard.
7. To turn off the buzzer just press any key of the programmer clock.
8. Return function and temperature knobs to 0 position.
9. Press  to reset the programmer clock.

### Notes

- At the end of cooking the heating elements will be deactivated. On the display,  turns off, A flashes and the buzzer sounds.
- It is not possible to set a cooking time of more than 10 hours.
- To reset the set program, press + and - buttons at the same time.
- To display the cooking time remaining after setting, press  for 2 seconds. Press  again. The display shows the text dur and the remaining cooking time in sequence.

### Setting programmed cooking

Programmed cooking is the function which allows the user to set a duration and specify a time at which automatically end the cooking operation.

1. Press  until  appears.
2. Press  again.  
The display will show the digits 0.00 and the text dur in sequence, while A flashes (for example the current time is 17:30).
3. Use the + or - button to set the required minutes of cooking (for example 1 hour).
4. Press .  
The text End will appear on the display in sequence with the pre-set cooking duration added to the current time (The display shows the current cooking end time. For example 18:30).
5. Use the + or - button to set a new cooking end time (for example 19:30).  
**Note:** Bear in mind that a few minutes for oven preheating must be added to the cooking time.
6. Wait 5 seconds without pressing any key in order for the function to activate.  
The current time and A appear on the display.
7. Select a function and a cooking temperature.
8. Symbol  disappears from the display. Cooking operation does not start until the planned time (for example, 18.30), that is the difference between the cooking end time and the cooking duration time. Press + and - at the same time to reset the set program.
9. When cooking is completed, an audible signal (buzzer) will be heard.
10. To turn off the buzzer just press any key of the programmer clock.
11. Return function and temperature knobs to 0 position.
12. Press  to reset the programmer clock.

## Notes

- At the end of cooking the heating elements will be deactivated. On the display,  turns off, A flashes and the buzzer sounds.
- It is not possible to set a cooking time of more than 10 hours.
- It is not possible to set a programmed cooking time of more than 24 hours.
- To reset the set program, press + and - buttons at the same time.
- To display the cooking time remaining after setting, press  for 2 seconds. Press  again. The display shows the text dur and the remaining cooking time in sequence.

## Setting minute minder timer

The minute minder timer does not stop the cooking operation but rather informs the user when the set time has run out.

The minute minder timer can be activated at any time.

1. Press  for two seconds.  
The display shows the digits 0.00 and  is flashing between the hours and minutes.
2. Use the + or - button to set the required minutes of cooking.
3. Wait 5 seconds without pressing any key in order for the function to activate.  
The current time and the symbols  and  appear on the display.

A buzzer will sound when the set time is reached.

4. To turn off the buzzer just press any key of the programmer clock.
5. Press  to reset the programmer clock.

**Note:** The minute minder timer can be set from 1 minute to a maximum of 23 hours and 59 minutes.

## Modifying the set data

Three different audible signals are available.

1. Press .
2. Use the + or - button to set the required minutes of cooking.

## Deleting the set data

Three different audible signals are available.

1. Press .
2. Press + and - buttons at the same time.
3. Switch off the oven manually if cooking is in progress.

## Switching off the acoustic signal

Press the "-" button to switch off the acoustic signal.

After seven minutes, the signal switches off automatically.

## Changing the audible signal

Three different audible signals are available.

1. Press the "+" and "-" buttons simultaneously.
2. Press the  button.  
The current audible signal is shown in the display panel, e.g. "Tone 1".
3. Press the "-" button to select a different audible signal.



## Cleaning agent

With good care and cleaning, your appliance will retain its appearance and remain fully functioning for a long time to come. We will explain here how you should correctly care for and clean your appliance.



### Warning – Risk of electric shock!

Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.



### Warning – Risk of burns!

The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.

## Suitable cleaning agents

Observe the following information to ensure that the different surfaces are not damaged by using the wrong type of cleaning agent.

Do not use any of the following

### on the hob:

- Undiluted washing-up liquid or dishwasher detergent,
- Abrasive materials, scouring sponges,
- Aggressive cleaners such as oven spray or stain removers,
- High-pressure cleaners or steam jet cleaners.

Do not use any of the following

### on the oven:

- Any harsh or abrasive cleaning agents,
- Cleaning agents with a high concentration of alcohol,
- Hard scouring pads or sponges,
- High-pressure cleaners or steam cleaners.

Wash new sponge cloths thoroughly before use.



### Warning – Risk of burns!

The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.

| Area                  | Cleaning                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Appliance exterior    | Hot soapy water:<br>Clean with a dish cloth and then dry with a soft cloth. Do not use glass cleaner or a glass scraper.                                                                                                                                                                                                                                                                                                             |
| Stainless steel front | Hot soapy water:<br>Clean with a dish cloth and then dry with a soft cloth.<br><br>Remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under such flecks.<br><br>Special stainless steel cleaning products suitable for hot surfaces are available from our after-sales service or from specialist retailers. Apply a very thin layer of the cleaning product with a soft cloth. |

|                                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Aluminium and plastic                      | Glass cleaner:<br>Clean with a soft cloth.                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Gas hob and pan supports                   | Hot soapy water.<br>Use very little water. Water must not be allowed to enter the appliance through the base of the burners.<br>Clean boiled-over liquids and spilt food immediately.<br>You can remove the pan supports. Do not clean the pan supports in the dishwasher.                                                                                                                                                                                                                                        |
| Gas burners, hot-plate                     | Remove the burner cups and caps, clean them with soapy water.<br>The gas outlet openings must remain free from obstruction.<br>Ignition plugs: Small, soft brush.<br>The gas burners only work properly when the ignition plugs are clean. Dry all parts thoroughly.<br>Ensure that they are positioned correctly when they are refitted.<br>The burner caps are coated in black enamel. The colour may change over time. This does not affect their function.<br>Do not clean the burner caps in the dishwasher. |
| Enamel surfaces (smooth surfaces)          | Hot soapy water:<br>Clean with a dish cloth and then dry with a soft cloth. Remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under such flecks.<br>Special stainless steel cleaning products suitable for hot surfaces are available from our after-sales service or from specialist retailers. Apply a very thin layer of the cleaning product with a soft cloth.                                                                                         |
| Enamel surfaces and self-cleaning surfaces | Observe the instructions for the surfaces of the cooking compartment that follow the table.                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Door panels                                | Hot soapy water:<br>Clean with a dish cloth and then dry with a soft cloth.<br>Do not use a glass scraper or a stainless steel scouring pad.                                                                                                                                                                                                                                                                                                                                                                      |
| Glass cover for the interior lighting      | Hot soapy water:<br>Clean with a dish cloth and then dry with a soft cloth.<br>If the cooking compartment is heavily soiled, use oven cleaner.                                                                                                                                                                                                                                                                                                                                                                    |
| Door seal<br>Do not remove.                | Hot soapy water:<br>Clean with a dish cloth.<br>Do not scour.                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Rails                                      | Hot soapy water:<br>Soak and clean with a dish cloth or brush.                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Accessories                                | Hot soapy water:<br>Soak and clean with a dish cloth or brush.<br>If there are heavy deposits of dirt, use a stainless steel scouring pad.                                                                                                                                                                                                                                                                                                                                                                        |

### Notes

- Slight differences in colour on the front of the appliance are caused by the use of different materials, such as glass, plastic and metal.
- Shadows on the door panels, which look like streaks, are caused by reflections made by the interior lighting.
- Enamel is baked on at very high temperatures. This can cause some slight colour variation. This is normal and does not affect operation.  
The edges of thin trays cannot be completely enamelled. As a result, these edges can be rough. This does not impair the anti-corrosion protection.

### Surfaces in the cooking compartment

The back wall and side parts in the cooking compartment are self-cleaning. You can tell this from the rough surface.

The cooking compartment floor and ceiling are enamelled and have smooth surfaces.

### Cleaning enamelled surfaces

Clean the smooth enamelled surfaces with a dish cloth and hot soapy water or a vinegar solution. Then dry with a soft cloth.

Soften baked-on food residues with a damp cloth and soapy water. Use stainless steel wire wool or oven cleaner to remove stubborn dirt.

Leave the cooking compartment open to dry after cleaning.

**Note:** Food residues can cause white deposits to form. These are harmless and do not affect how the appliance works. You can remove these residues using lemon juice if required.

### Cleaning self-cleaning surfaces

The self-cleaning surfaces are coated with a porous, matte ceramic layer. This coating absorbs and dispels splashes from baking and roasting while the appliance is in operation.

If the self-cleaning surfaces no longer clean themselves sufficiently and dark stains appear, they can be cleaned using the cleaning function. To do this, refer to the information in the relevant section.

### Caution!

Do not use oven cleaner on self-cleaning surfaces. This will damage the surfaces. If oven cleaner does get onto these surfaces, dab it off immediately using water and a sponge cloth. Do not rub the surface and do not use abrasive cleaning aids.

## Keeping the appliance clean

Always keep the appliance clean and remove dirt immediately so that stubborn deposits of dirt do not build up.

### Tips

- Clean the cooking compartment after each use. This will ensure that dirt cannot be baked on.
- Always remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately.
- Use the universal pan for baking very moist cakes.
- Use suitable ovenware for roasting, e.g. a roasting dish.

## Cleaning the cooking compartment

1. Pour 0.4 litres of water into the centre of the cooking compartment floor.
2. Set the type of heating .
3. Use the temperature controller to set 50 °C.
4. Switch off the appliance after 18 minutes.
5. Allow the appliance to cool down.
6. Clean the cooking compartment with a cloth.

### Warning – Risk of burns!


The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.

## Rails

### Removing the hook-in racks

The hook-in racks are each fixed to the side panels of the cooking compartment at three points.

1. Grip the front of the hook-in rack and pull it to the middle of the cooking compartment. The front hook of the hook-in rack is released from the hole.
2. Fold out the hook-in rack further and pull it from the rear holes of the side panel.
3. Hold the catalytic cooking compartment panel in place.
4. Remove the hook-in rack from the cooking compartment.



### Inserting the hook-in rack

1. Hold the catalytic cooking compartment panel in place.
2. Insert the hooks of the hook-in rack into the rear holes in the side panel.
3. Press the front hook of the hook-in rack into the hole.

## Appliance door


With good care and cleaning, your appliance will retain its appearance and remain fully functional for a long time to come. This will tell you how to clean the appliance door.

### Removing and installing the door panels


To facilitate cleaning, you can remove the glass panels from the oven door.

#### Removing the door panels

1. Open the oven door fully.
  2. Lock both hinges on the left and right using the locking pin.
- Note:** The locking pins must be fully inserted into the holes in the hinges.



3. Lift the bottom of the inner panel slightly until the fastening pins come out of the holder (1).
  4. Carefully lift the top of the inner panel until the fastening pins come out of the holder (2).
- Caution!**  
When lifting the inner panel, the middle panel may stick to the inner panel. Ensure that the middle panel does not fall.



5. Remove the inner panel.

Clean the panels with glass cleaner and a soft cloth.

#### **Warning – Risk of injury!**

Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.

### Fitting the door panels



1. Reinsert the inner panel.  
**Note:** All four fastening pins must engage in the holders provided for them.
2. Remove the locking pins and close the oven door.

### Removing and fitting the appliance door

If the oven is very heavily soiled, the oven door can be removed for easier cleaning. Normally, however, this is not necessary.

#### Removing the appliance door

1. Open the oven door fully.
  2. Lock both hinges on the left and right using the locking pin (a).
- Note:** The locking pins must be fully inserted into the holes in the hinges.
3. Grip the oven door on either side with both hands and close the oven door by approx. 30° (b).




4. Raise the oven door slightly and pull it out.  
**Note:** Do not fully close the oven door. The hinges could become bent and the enamel could be damaged.

## Fitting the appliance door

1. Grip the oven door on either side with both hands.
2. Slide the hinges into the slots in the oven **(a)**.

**Note:** The notch below the hinges must engage into the frame of the oven **(b)**.



3. Lower the door downwards.
4. Remove the locking pins.

### **Warning – Risk of injury!**

Do not reach into the hinge if the oven door falls out unintentionally or a hinge snaps closed. Call after-sales service.

### **Warning – Risk of injury!**

The door may not close properly if the door hinges have not engaged correctly. This will allow heat to escape and the parts of the appliance may become very hot. To prevent this from happening, remove the door again. Then refit the door as shown in the drawing, making sure that the groove on the underside of the hinges engages in the oven frame.

## ? Trouble shooting

### ! Warning – Risk of injury!

Incorrect repairs may cause serious hazards. Repairs to the appliance must only be carried out by a qualified technician. If repairs are required, contact the after-sales service.

### Fault table

| Fault                                                                                   | Possible cause                                             | Remedy/information                                                           |
|-----------------------------------------------------------------------------------------|------------------------------------------------------------|------------------------------------------------------------------------------|
| The appliance does not work.                                                            | The circuit breaker is faulty                              | Look in the fuse box and check that the circuit breaker is in working order. |
|                                                                                         | Power cut                                                  | Check whether the kitchen light works.                                       |
| Zeros flash in the display.                                                             | Power cut                                                  | Reset the time.                                                              |
| The oven light has failed.                                                              | Faulty oven light                                          | Change the oven light bulb. (See section "Replacing the oven light")         |
| The gas burner does not ignite.                                                         | Power cut or damp ignition plugs                           | Light the gas burner with a gas lighter or a match.                          |
| The oven does not heat up.                                                              | Faulty fuse.                                               | Check and, if required, replace the circuit breaker.                         |
|                                                                                         | The function selector has not been set.                    | Set the function selector.                                                   |
| All dishes that are prepared in the oven burn within an extremely short period of time. | Faulty thermostat                                          | Call the after-sales service.                                                |
| The door panel steams up when the oven is hot.                                          | Normal occurrence; caused by the difference in temperature | Not possible; this has no effect on oven performance.                        |

## Replacing the oven light bulb


If the oven light bulb fails, it must be replaced. Replacement heat-resistant bulbs can be obtained from the after-sales service or from specialist retailers. Please specify the E number and FD number of your appliance. Do not use any other type of bulb.

### ! Warning – Risk of electric shock!

When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

1. Allow the cooking compartment to cool down.
2. Open the appliance door.
3. Place a tea towel in the cooking compartment to prevent damage.
4. Remove the hook-in racks.
5. Remove the glass cover. To do this, open the glass cover at the front with your hand. Should you experience difficulties removing the glass cover, use a spoon to help.

6. Remove the oven light bulb.



7. Replace the oven light bulb with a bulb of the same type:  
**Voltage:** 230 V;  
**Power:** 40 W;  
**Fitting:** G9;  
**Temperature resistance:** 300 °C
8. Refit the glass cover for the oven light bulb.
9. Refit the hook-in racks.
10. Remove the tea towel.
11. Switch the circuit breaker back on.
12. Check that the oven lighting is working again.

 **Customer service**

Our after-sales service is there for you if your appliance needs to be repaired. You will find the address and telephone number of your nearest after-sales service centre in the phone book. The after-sales service centres listed will also be happy to give you the details of an after-sales service point near you.

**E number and FD number** Please quote the E number (product number) and FD number (production number) of the appliance when contacting the after-sales service. The rating plate and the relevant numbers can be found on the inside of the storage compartment flap. So that you do not have to spend a long time looking for it if there is a fault, you can enter the data for your appliance here now.

|                                                                                                       |    |
|-------------------------------------------------------------------------------------------------------|----|
| E no.                                                                                                 | FD |
| After-sales service  |    |

## Tested for you in our cooking studio

Here, you can find a selection of dishes and the ideal settings for them. We will show you which type of heating and temperature are best suited to your dish. You will get information on suitable cooking accessories and the height at which they should be placed in the oven. You will also get tips about cookware and preparation methods.

**Note:** A lot of steam can build up in the cooking compartment when cooking food. Your appliance is very energy-efficient and radiates very little heat to its surroundings during operation. Due to the high difference in temperature between the appliance interior and the external parts of the appliance, condensation may build up on the door, control panel or adjacent kitchen cabinet panels. This is a normal physical phenomenon. Condensation can be reduced by preheating the oven or opening the door carefully.

### Table of dishes

| Dish                   | Weight (in kg) | Type of heating                                                                     | Shelf position | Temperature in °C | Cooking time in mins       |
|------------------------|----------------|-------------------------------------------------------------------------------------|----------------|-------------------|----------------------------|
| Lasagne                | 3-4            |    | 1              | 220-230           | 45-50                      |
| Pasta bake             | 3-4            |    | 1              | 220-230           | 45-50                      |
| Roast veal             | 2              |    | 2              | 180-190           | 90-100                     |
| Pork                   | 2              |    | 2              | 180-190           | 70-80                      |
| Sausages               | 1.5            |    | 4              | Max.              | 15                         |
| Roast beef             | 1              |    | 2              | 200               | 40-45                      |
| Roast rabbit           | 1.5            |    | 2              | 180-190           | 70-80                      |
| Turkey breast          | 2              |    | 2              | 180-190           | 110-120                    |
| Pork neck joint        | 2-3            |   | 2              | 180-190           | 170-180                    |
| Roast chicken          | 1.2            |  | 2              | 180-190           | 65-70                      |
| Pork cutlet            | 1.5            |  | 4              | Max.              | 1st side 15<br>2nd side 5  |
| Spare ribs             | 1.5            |  | 4              | Max.              | 1st side 10<br>2nd side 10 |
| Bacon                  | 0.7            |  | 5              | Max.              | 1st side 7<br>2nd side 8   |
| Fillet of pork         | 1.5            |  | 4              | Max.              | 1st side 10<br>2nd side 5  |
| Fillet of beef         | 1              |  | 5              | Max.              | 1st side 10<br>2nd side 7  |
| Large rainbow trout    | 1.2            |  | 2              | 150-160           | 35-40                      |
| Monkfish               | 1.5            |  | 2              | 160               | 60-65                      |
| Turbot                 | 1.5            |  | 2              | 160               | 45-50                      |
| Pizza                  | 1              |  | 2              | Max.              | 8-9                        |
| Bread                  | 1              |  | 2              | 190-200           | 25-30                      |
| Focaccia               | 1              |  | 2              | 180-190           | 20-25                      |
| Bundt cake             | 1              |  | 2              | 160               | 55-60                      |
| Fruit flan             | 1              |  | 2              | 160               | 35-40                      |
| Cheesecake             | 1              |  | 2              | 160-170           | 25-60                      |
| Shortcrust pastry tart | 1              |  | 2              | 160               | 20-25                      |
| Parfait cake           | 1.2            |  | 2              | 160               | 55-60                      |
| Cream puffs            | 1.2            |  | 2              | 180               | 80-90                      |
| Sponge cake            | 1              |  | 2              | 150-160           | 55-60                      |
| Rice pudding           | 1              |  | 2              | 160               | 55-60                      |
| Brioche                | 0.6            |  | 2              | 160               | 30-35                      |
| Roast chicken*         | 1-2            |  | 1              | 250-260           | 65-70                      |
| Pork loin*             | 3-4            |  | 1              | 220-230           | 120-140                    |

\* 0.5 - Pour 0.7 litres of water into the baking tray. This will produce less smoke and the moisture will keep the meat tender.

## Tips for using your appliance

Here you will find a selection of tips on ovenware and preparation methods.

### Notes

- Use the accessories provided. Additional accessories may be obtained as special accessories from specialist retailers or from the after-sales service.  
Before using the oven, remove any unnecessary accessories and ovenware from the cooking compartment.
- Always use an oven cloth or oven gloves when taking accessories or cookware out of the cooking compartment.

### Baking tips

|                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| You want to find out whether the cake is completely cooked in the middle.                                           | Push a cocktail stick into the highest point on the cake. If the cocktail stick comes out clean with no dough residue, the cake is ready.                                                                                                                                                                                                                   |
| The cake collapses.                                                                                                 | Next time, use less liquid. Alternatively, set the temperature to be 10 °C lower and extend the baking time. Adhere to the specified ingredients and preparation instructions in the recipe.                                                                                                                                                                |
| The cake has risen in the middle but is lower around the edge.                                                      | Only grease the base of the springform cake tin. After baking, loosen the cake carefully with a knife.                                                                                                                                                                                                                                                      |
| The fruit juice overflows.                                                                                          | Next time, use the universal pan.                                                                                                                                                                                                                                                                                                                           |
| Small baked items stick to one another during baking.                                                               | There should be a gap of approx. 2 cm around each item. This gives enough space for the baked items to expand well and brown on all sides.                                                                                                                                                                                                                  |
| The cake is too dry.                                                                                                | Set the temperature 10 °C higher and shorten the baking time.                                                                                                                                                                                                                                                                                               |
| The cake is generally too light in colour.                                                                          | If the shelf position and the cookware are correct, then you should increase the temperature if necessary or extend the baking time.                                                                                                                                                                                                                        |
| The cake is too light on top, and too dark underneath.                                                              | Bake the cake one level higher in the oven the next time.                                                                                                                                                                                                                                                                                                   |
| The cake is too dark on top, and too light underneath.                                                              | Bake the cake one level lower in the oven the next time. Select a lower temperature and extend the baking time.                                                                                                                                                                                                                                             |
| Cakes baked in a tray or tin are too brown at the back.                                                             | Place the baking tray in the middle of the accessories, not directly against the back wall.                                                                                                                                                                                                                                                                 |
| The whole cake is too dark.                                                                                         | Select a lower temperature next time and extend the baking time if necessary.                                                                                                                                                                                                                                                                               |
| The cake is unevenly browned.                                                                                       | Select a slightly lower temperature.<br>Protruding greaseproof paper can affect the air circulation. Always cut greaseproof paper to size.<br>Ensure that the baking tin does not stand directly in front of the openings in the cooking compartment back wall.<br>When baking small items, you should use similar sizes and thicknesses wherever possible. |
| You were baking on several levels. The items on the top baking tray are darker than those on the lower baking tray. | Always select hot air when baking on several levels. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.                                                                                                                                                           |
| The cake looks good, but is not cooked properly in the middle.                                                      | Use a lower temperature and bake slightly longer; if necessary, add slightly less liquid. For cakes with a moist topping, bake the base first. Sprinkle it with almonds or breadcrumbs and then place the topping on top.                                                                                                                                   |
| The cake cannot be turned out of the dish when it is turned upside down.                                            | Allow the cake to cool down for 5 to 10 minutes after baking. If it still sticks, carefully loosen the cake around the edges again using a knife. Turn the cake tin upside down again and cover it several times with a cold, wet cloth. Next time, grease the baking tin/dish and sprinkle with breadcrumbs.                                               |

## Tips for Roasting and Braising

|                                                                                           |                                                                                                                                                |
|-------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| The roast is too dark and the crackling is burned in places, and/or the roast is too dry. | Check the shelf position and temperature. Select a lower temperature the next time and reduce the roasting time if necessary.                  |
| The crackling is too thin.                                                                | Increase the temperature or switch on the grill briefly at the end of the roasting time.                                                       |
| The roast looks good but the juices are burnt.                                            | Next time, use a smaller roasting dish and add more liquid if necessary.                                                                       |
| The roast looks good but the juices are too clear and watery.                             | Next time, use a larger roasting dish and add less liquid if necessary.                                                                        |
| The meat gets burned during braising.                                                     | The roasting dish and lid must fit together well and close properly.<br>Reduce the temperature and add more liquid when braising if necessary. |

### ATTENTION!

Acidic food may damage the grid

- Do not place acidic food, such as fruit or food with an acidic marinade directly on the pan support.

### Information for those allergic to nickel

In rare cases, small amounts of nickel may pass into the food.

## Acrylamide in foodstuffs

Acrylamide is mainly produced in grain and potato products prepared at high temperatures, such as potato crisps, chips, sliced bread, bread rolls, bread or fine baked goods (biscuits, gingerbread, spiced biscuit).

| Tips for keeping acrylamide to a minimum |                                                                                                                                                                                                                               |
|------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| General                                  | <ul style="list-style-type: none"> <li>■ Keep cooking times as short as possible.</li> <li>■ Cook food until it is golden brown, but not too dark.</li> <li>■ Large, thick pieces of food contain less acrylamide.</li> </ul> |
| Baking                                   | With top/bottom heating at max. 200 °C.<br>With hot air at max. 180 °C.                                                                                                                                                       |
| Biscuits                                 | With top/bottom heating at max. 190 °C.<br>With hot air at max. 170 °C.<br>Egg or egg yolk reduces the production of acrylamide.                                                                                              |
| Oven chips                               | Spread out a single layer evenly on the baking tray. Cook at least 400 g at once on a baking tray so that the chips do not dry out.                                                                                           |



A series of horizontal lines for writing, starting from the top right of the pencil icon and extending across the page.



A series of horizontal lines for writing, starting from the top right of the pencil icon and extending across the page.

## نصائح بخصوص التحمير والطهي على نار هادئة

|                                                                                                          |                                                                                                                                                |
|----------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| اكتسب اللحم لونًا بنيًا قاتمًا للغاية واحترقت بعض المواضع من سطحها الخارجي و/أو أصبح اللحم جافًا للغاية. | تحقق من مستوى الإدخال ودرجة الحرارة. قم في المرة القادمة باختيار درجة حرارة أقل نسبيًا وتقصير مدة التحمير عند اللزوم.                          |
| القشرة رفيعة للغاية.                                                                                     | قم بزيادة درجة الحرارة أو قم بتشغيل الشواية لفترة قصيرة بعد انتهاء مدة التحمير.                                                                |
| قطعة اللحم تبدو بحالة جيدة، ولكن الصوص محترق.                                                            | اختر في المرة القادمة إناء تحمير أصغر نسبيًا وأضف عند اللزوم المزيد من السائل.                                                                 |
| قطعة اللحم تبدو بحالة جيدة، ولكن الصوص فاتح اللون للغاية ومخفف للغاية.                                   | اختر في المرة القادمة إناء تحمير أكبر نسبيًا وأضف عند اللزوم كمية أقل من السائل.                                                               |
| عند الطهي على نار هادئة يحترق اللحم.                                                                     | يجب أن يكون إناء التحمير والغطاء متوائمين ويغلقان جيدًا. قم بتقليل درجة الحرارة وأضف عند الحاجة كمية أخرى من السائل أثناء الطهي على نار هادئة. |

## تنبيه!

المواد الغذائية المحتوية على أحماض يمكن أن تلحق ضررًا بالشبكة السلوكية

❖ لا تضع المواد الغذائية المحتوية على أحماض مثل الفواكه أو الأطعمة المراد شواؤها المتبلّة بتبيلة محتوية على أحماض على الشبكة السلوكية مباشرة.

## إرشاد للمصابين بحساسية ضد النيكل

يمكن أن تنتقل بقايا قليلة من النيكل إلى المواد الغذائية في حالات نادرة.

## الأكريلاميد في المواد الغذائية

ينتج الأكريلاميد بشكل رئيسي في منتجات الحبوب والبطاطس المُعدة في درجات حرارة عالية، مثل رقائق البطاطس واليوم فري والخبز التوست والخبز الملفوف والخبز أو المخبوزات الرقيقة (البسكويت، وخبز الزنجبيل، والبسكويت المتبل).

## نصائح للحد من الأكريلاميد عند تحضير الطعام

|                        |                                                                                                                                                                                                                         |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| نقاط عامة              | <ul style="list-style-type: none"> <li>■ قلل أوقات الطهي إلى الحد الأدنى.</li> <li>■ قم بطهي الوجبات حتى يصبح لونها بني ذهبي وليس قاتمًا للغاية.</li> <li>■ القطع الكبيرة من الطعام تحتوي على أكريلاميد أقل.</li> </ul> |
| إعداد المخبوزات        | بالتسخين العلوي/السفلي بحد أقصى 200°م.<br>بالهواء الساخن بحد أقصى 180°م.                                                                                                                                                |
| بسكويت                 | بالتسخين العلوي/السفلي بحد أقصى 190°م.<br>بالهواء الساخن بحد أقصى 170°م.<br>البيض أو صفار البيض يقلل من إنتاج مادة الأكريلاميد.                                                                                         |
| بطاطس اليوم فري بالفرن | قم بتوزيع طبقة واحدة منها بالتساوي على لوح الخبز. قم بإعداد 400 جم على الأقل على كل لوح، وذلك حتى لا تجف بطاطس اليوم فري.                                                                                               |

| الوجبة                                                                                     | الوزن (بالكجم) | نوع التسخين                                                                       | مستوى الإدخال | درجة الحرارة °م | المدة بالدقائق |
|--------------------------------------------------------------------------------------------|----------------|-----------------------------------------------------------------------------------|---------------|-----------------|----------------|
| فطائر بريوش                                                                                | 0.6            |  | 2             | 160             | 30-35          |
| دجاج مشوي*                                                                                 | 1-2            |  | 1             | 250-260         | 65-70          |
| لحم خاصرة دسم*                                                                             | 3-4            |  | 1             | 220-230         | 120-140        |
| * أضف 0,5 - 0,7 لتر من الماء في لوح الخبز. فبذلك يقل الدخان وتحافظ الرطوبة على اللحم طريا. |                |                                                                                   |               |                 |                |

## نصائح الاستخدام

تجد هنا مجموعة من النصائح حول أواني الطهي وطرق التحضير.

### ملاحظات

- استخدم الكماليات الموردة مع الجهاز. ويمكنك الحصول على الكماليات الإضافية ككماليات خاصة من المتاجر المتخصصة أو من خدمة العملاء.
- قبل استخدام الفرن، أخرج الكماليات غير الضرورية والأواني من حيز الطهي.
- استخدم دائمًا فوطة أواني عند إخراج الكماليات أو الأواني الساخنة من حيز الطهي.

## نصائح لإعداد المخبوزات

|                                                                                                               |                                                                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| تريد التحقق من نضج الكيك.                                                                                     | اغرس خلة خشبية في الكيك من أعلى نقطة. إذا لم يلتصق العجين بالخلة، تكون الكيك قد نضجت.                                                                                                                                                                                                 |
| الكيك يهبط.                                                                                                   | استخدم كمية أقل من السائل في المرة التالية. أو اضبط درجة حرارة أقل بمقدار 10°م وقم بإطالة زمن الخبز. احرص على مراعاة الإضافات المذكورة وإرشادات الإعداد الواردة في الوصفة.                                                                                                            |
| الكيك مرتفع من المنتصف ولكنه منخفض عند الحواف.                                                                | ادهن فقط قاعدة صينية الكيك القابلة لفصل الجوانب بالزبدة. بعد الخبز، افصل الكيك بحرص باستخدام سكين.                                                                                                                                                                                    |
| عصير الفواكه يفيض.                                                                                            | استخدم اللوح متعدد الاستخدامات في المرة التالية.                                                                                                                                                                                                                                      |
| المخبوزات الصغيرة تلتصق ببعضها عند خبزها.                                                                     | ينبغي أن يكون هناك فاصل بمقدار 2 سم تقريبًا بين كل قطعة والأخرى. وهذا يسمح بوجود حيز كاف لتمدد قطع المخبوزات بشكل جيد ولتحميرها من جميع الجهات.                                                                                                                                       |
| الكيك جاف جدًا.                                                                                               | اضبط درجة حرارة أعلى بمقدار 10°م وقم بتقصير زمن الخبز.                                                                                                                                                                                                                                |
| الكيك بصفة إجمالية فاتح اللون للغاية.                                                                         | في حالة استخدام مستوى الإدخال الصحيح والكماليات الصحيحة، قم عند اللزوم بزيادة درجة الحرارة أو إطالة زمن الخبز.                                                                                                                                                                        |
| الكيك من أعلى فاتح للغاية، لكنه من أسفل داكن للغاية.                                                          | أدخل الكيك في المرة القادمة على مستوى أعلى.                                                                                                                                                                                                                                           |
| الكيك من أعلى داكن للغاية، لكنه من أسفل فاتح للغاية.                                                          | أدخل الكيك في المرة القادمة على مستوى أدنى. اختر درجة حرارة أقل نسبيًا وقم بإطالة زمن الخبز.                                                                                                                                                                                          |
| الكيك المستدير أو المستطيل داكن للغاية من الخلف.                                                              | لا تضع صينية إعداد المخبوزات على الجدار الخلفي مباشرة، وإنما ضعها في المنتصف على ملحق الكماليات.                                                                                                                                                                                      |
| الكيك بصفة إجمالية داكن اللون للغاية.                                                                         | قم في المرة القادمة باختيار درجة حرارة أقل نسبيًا وإطالة زمن الخبز عند اللزوم.                                                                                                                                                                                                        |
| المخبوزات محمرة بشكل غير متساوٍ.                                                                              | اختر درجة حرارة أقل بعض الشيء. أيضا ورق إعداد المخبوزات البارز يمكن أن يؤثر على تدوير الهواء. قم بتقطيع ورق إعداد المخبوزات دائماً بالمقاس المناسب.                                                                                                                                   |
| الخبز كان على عدة مستويات. قطع المخبوزات الموجودة على اللوح العلوي أكثر تحميراً من الموجودة على اللوح السفلي. | احرص على مراعاة عدم وضع صينية إعداد المخبوزات مباشرة أمام فتحات الجدار الخلفي لحيز الطهي. عند إعداد المخبوزات الصغيرة ينبغي عليك قدر الإمكان استخدام قطع بنفس الحجم والسُمك.                                                                                                          |
| فقد يبدو الكيك جيداً من الخارج، إلا أنه لم ينضج من الداخل.                                                    | اختر دائماً وضع الهواء الساخن رباعي الاتجاهات عند الخبز على عدة مستويات. المخبوزات التي يتم إدخالها في وقت واحد على ألواح أو في صواني لا تنضج بالضرورة في وقت واحد.                                                                                                                   |
| الكيك لا يفصل عند قلبه.                                                                                       | قم بإعداد المخبوزات بدرجة حرارة أدنى نسبياً ولمدة أطول بعض الشيء وعند اللزوم أضف كمية أقل نسبياً من السائل. بالنسبة للكيك ذي الطبقة العلوية الرطبة قم أولاً بإجراء إعداد مسبق لقاعدة الكيك. قم برشه باللوز أو الخبز المدقوق ثم ضع الطبقة العلوية فوقه.                                |
|                                                                                                               | اترك الكيك يبرد بعد إعداده لمدة من 5 حتى 10 دقائق أخرى. وإذا استمر تعذر فصله بعد ذلك، فقم بفصل الكيك من الجوانب مرة أخرى بحرص باستخدام سكين. اقلب الكيك مجدداً وقم بتغطية الصينية عدة مرات بقطعة قماش رطبة وباردة. قم في المرة القادمة بدهن الصينية بالزبدة ونثر الخبز المدقوق عليها. |

## الأطباق التي تم اختبارها في ستوديو الطهي الخاص بنا

ستجد هنا باقة من الأطعمة وأوضاع الضبط المثالية لها. وسوف نعرض لك نوع التسخين ودرجة الحرارة الأنسب للطعام الذي تعدّه. كما تجد بيانات حول الكماليات المناسبة ومستوى الارتفاع الذي ينبغي أن تُركب عليه. وهناك أيضًا نصائح حول أواني الطهي وطرق التحضير.

### جدول الأطباق

| الوجبة            | الوزن (بالكجم) | نوع التسخين | مستوى الإدخال | درجة الحرارة °م | المدة بالدقائق           |
|-------------------|----------------|-------------|---------------|-----------------|--------------------------|
| لازانيا           | 4-3            | ☐           | 1             | 230-220         | 50-45                    |
| معكرونة فرن       | 4-3            | ☐           | 1             | 230-220         | 50-45                    |
| لحم عجل مشوي      | 2              | ☐           | 2             | 190-180         | 100-90                   |
| لحم دسم           | 2              | ☐           | 2             | 190-180         | 80-70                    |
| السجق (النقانق)   | 1.5            | ☐           | 4             | الحد الأقصى     | 15                       |
| روست بيف          | 1              | ☐           | 2             | 200             | 45-40                    |
| لحم أرانب         | 1.5            | ☐           | 2             | 190-180         | 80-70                    |
| صدر ديك رومي      | 2              | ☐           | 2             | 190-180         | 120-110                  |
| لحم رقبة دسم مشوي | 3-2            | ☐           | 2             | 190-180         | 180-170                  |
| دجاج مشوي         | 1.2            | ☐           | 2             | 190-180         | 70-65                    |
| كستليتة لحم دسم   | 1.5            | ☐           | 4             | الحد الأقصى     | 1. صفحة 15<br>2. صفحة 5  |
| ريش               | 1.5            | ☐           | 4             | الحد الأقصى     | 1. صفحة 10<br>2. صفحة 10 |
| لحم بيبكون        | 0.7            | ☐           | 5             | الحد الأقصى     | 1. صفحة 7<br>2. صفحة 8   |
| لحم دسم فيليه     | 1.5            | ☐           | 4             | الحد الأقصى     | 1. صفحة 10<br>2. صفحة 5  |
| سكالوب فيليه      | 1              | ☐           | 5             | الحد الأقصى     | 1. صفحة 10<br>2. صفحة 7  |
| سمك التراوت       | 1.2            | ☐           | 2             | 160-150         | 40-35                    |
| سمك الراهب        | 1.5            | ☐           | 2             | 160             | 65-60                    |
| سمك الترس         | 1.5            | ☐           | 2             | 160             | 50-45                    |
| بيتزا             | 1              | ☐           | 2             | الحد الأقصى     | 9-8                      |
| خبز               | 1              | ☐           | 2             | 200-190         | 30-25                    |
| فوكاتشيا          | 1              | ☐           | 2             | 190-180         | 25-20                    |
| كيك حلقي          | 1              | ☐           | 2             | 160             | 60-55                    |
| كيك فواكه         | 1              | ☐           | 2             | 160             | 40-35                    |
| كيك ريكوتا        | 1              | ☐           | 2             | 170-160         | 60-25                    |
| فطائر الشورت كرس  | 1              | ☐           | 2             | 160             | 25-20                    |
| كيك باراديس       | 1.2            | ☐           | 2             | 160             | 60-55                    |
| كريم باف          | 1.2            | ☐           | 2             | 180             | 90-80                    |
| كيك إسفنجي        | 1              | ☐           | 2             | 160-150         | 60-55                    |
| أرز باللبن        | 1              | ☐           | 2             | 160             | 60-55                    |

\* أضف 0,5 - 0,7 لتر من الماء في لوح الخبز. فبذلك يقل الدخان وتحافظ الرطوبة على اللحم طريا.

## خدمة العملاء

إذا احتاج جهازك للإصلاح، فمركزنا لخدمة العملاء هو وجهتك المناسبة. ستجد عنوان أقرب مركز خدمة عملاء لك ورقمه الهاتفي في دليل الهاتف. كما ستخبرك مراكز خدمة العملاء الأخرى بكل سرور بأقرب موقع خدمة عملاء منك.

**رقم المنتج E ورقم الصنع FD**

عندما تتصل بمركزنا لخدمة العملاء، يرجى إبلاغهم برقم E (رقم المنتج) ورقم FD (رقم الصنع) الخاصين بالجهاز. وسوف تجد لوحة الصنع المدون بها الأرقام على باطن غطاء درج الحفظ. ولكي لا تضطر للبحث لوقت طويل عن هذه البيانات في حالة حدوث خلل، يمكنك تدوين بيانات جهازك هنا الآن.

|                                                                                                  |        |
|--------------------------------------------------------------------------------------------------|--------|
| رقم المنتج E-Nr.                                                                                 | رقم FD |
| خدمة العملاء  |        |


## ؟ الاختلالات، ما العمل؟

**⚠ تحذير - خطر الإصابة!**  
القيام بالإصلاحات بطريقة غير سليمة يمكن أن يتسبب في أخطار بالغة.  
لذا لا يجوز إجراء إصلاحات على الجهاز إلا بمعرفة الفنيين المتخصصين.  
وعند الحاجة لإجراء إصلاح، اتصل بمركز خدمة العملاء.

### جدول الاختلالات

| الخلل                                                        | السبب المحتمل                                     | كيفية التصرف/إرشادات                                  |
|--------------------------------------------------------------|---------------------------------------------------|-------------------------------------------------------|
| الجهاز لا يعمل.                                              | المصهر تالف                                       | افحص صندوق المصاهر وتأكد أن المصهر على ما يرام.       |
| انقطاع التيار الكهربائي                                      | انقطاع التيار الكهربائي                           | تأكد من عمل مصباح المطبخ.                             |
| تومض أصفار في الشاشة.                                        | انقطاع التيار الكهربائي                           | اضبط الساعة من جديد.                                  |
| تعطل إضاءة الفرن.                                            | لمبة الفرن تالفة                                  | قم بتغيير لمبة الفرن. (انظر موضوع «تغيير لمبة الفرن») |
| لا يتم إشعال شعلة الغاز.                                     | انقطاع التيار الكهربائي أو رطوبة في شمعات الإشعال | قم بإشعال شعلة الغاز باستخدام ولاعة غاز أو عود ثقاب.  |
| لا يقوم الفرن بالتسخين.                                      | المصهر تالف.                                      | افحص المصهر أو قم بتغييره.                            |
| لم يتم ضبط مفتاح اختيار الوظيفة.                             | لم يتم ضبط مفتاح اختيار الوظيفة.                  | اضبط مفتاح اختيار الوظيفة.                            |
| جميع الأطعمة التي يتم إعدادها في الفرن تحترق بعد فترة قصيرة. | الترموستات تالف                                   | اتصل بخدمة العملاء.                                   |
| يتكثف بخار ماء على زجاج الباب عند تسخين الفرن.               | ظاهرة عادية نظرًا لاختلاف درجة الحرارة            | غير متاح: لا تأثير لها على الكفاءة الوظيفية.          |

### 6. اجذب لمبة الفرن للخارج.



### 7. استبدل لمبة الفرن بأخرى من نفس النوع:

الجهود الكهربائي: 230 فولت،

القدرة: 40 واط،

الدواة: G9،

مقاومة الحرارة: 300°م

### 8. أعد تركيب الغطاء الزجاجي للمبة الفرن.

### 9. قم بتركيب شبكات قضبان التعليق.

### 10. أخرج فوطة الأواني مرة أخرى.

### 11. أعد توصيل المصهر.

### 12. تأكد أن إضاءة الفرن تعمل من جديد.

## تغيير لمبة الفرن

يجب تغيير لمبة الفرن في حالة تلفها. يمكنك الحصول على اللمبات البديلة التي تتحمل سخونة من مركز خدمة العملاء أو من المتاجر المتخصصة. ويرجى ذكر رقم E ورقم FD لجهازك. لا تستخدم لمبات من أنواع أخرى.

### ⚠ تحذير - خطر الصعق الكهربائي!

يراعى عند تغيير لمبة حيز الطهي أن ملامسات دواة اللمبة يسري فيها تيار كهربائي. قبل تغيير اللمبة، انزع القابس الكهربائي من المقبس أو افصل المصهر الموجود في صندوق المصاهر.

1. اترك حيز الطهي حتى يبرد.
2. افتح باب الجهاز.
3. ضع فوطة أواني في حيز الطهي لتجنب حدوث أضرار.
4. اخلع شبكات قضبان التعليق.
5. اخلع الغطاء الزجاجي. للقيام بذلك افتح الغطاء الزجاجي من الأمام بيدك. في حالة تعذر خلع الغطاء الزجاجي استعن بملعقة.

## تركيب زجاج الباب

**⚠ تحذير - خطر الإصابة!**  
في حالة سقوط باب الفرن للخارج دون قصد أو في حالة انغلاق مفصلة بشكل ارتدادي، لا تدخل يدك في المفصلة. اتصل بخدمة العملاء.

**⚠ تحذير - خطر الإصابة!**  
إذا لم يتم تثبيت مفصلات الباب بشكل سليم، فلن يتسنى غلق الباب بشكل صحيح، ويمكن أن تتسرب السخونة للخارج وتصبح أجزاء الجهاز ساخنة للغاية. ولتجنب حدوث ذلك، قم بفك الباب مرة أخرى. ثم أعد تركيب الباب طبقاً للرسم المبين، بحيث يثبت الحز بالجزء السفلي للمفصلة في إطار الفرن.


1. أعد تركيب الزجاج الداخلي.  
**ملاحظة:** يجب أن تستقر جميع خوابير التثبيت الأربعة في مواضع التثبيت المخصصة لها.
2. قم بإزالة خوابير التأمين وأغلق باب الفرن.

## فك وتركيب باب الجهاز

يمكن خلع باب الفرن في حالة الاتساخات العنيدة لضمان مستوى تنظيف أفضل. ولا ننصح بذلك مع الاتساخات العادية.

## فك باب الجهاز


1. افتح باب الفرن تماماً.
2. قم بتثبيت المفصلتين اليسرى واليمنى بخابور التأمين (a).
3. **ملاحظة:** يجب إدخال خوابير التأمين في تجاويف المفصلات تماماً. أمسك باب الفرن من الجانبين بكلتا يديك ثم أغلقه بزاوية حوالي 30° (b).



4. ارفع باب الفرن قليلاً واسحبه للخارج.  
**ملاحظة:** لا تغلق باب الفرن تماماً. حيث يمكن أن تنثني المفصلات وتسبب أضراراً بطبقة المينا (الإيناميل).

## تركيب باب الجهاز

1. أمسك باب الفرن بكلتا يديك من الجانبين.
2. أدخل المفصلات في تجاويف الفرن (a).
- ملاحظة:** الحز السفلي بالمفصلات يجب أن يثبت في إطار الفرن (b).



3. أنزل الباب لأسفل.
4. أخرج خوابير التأمين.

## باب الجهاز


العناية الجيدة بجهازك وتنظيفه باهتمام يحافظ على جماله وكفاءته الوظيفية لفترة طويلة. تتعرف هنا على كيفية تنظيف باب الجهاز.

### فك وتركيب زجاج الباب

يمكنك فك الألواح الزجاجية من باب الفرن لإجراء عملية التنظيف بشكل أفضل.

#### فك زجاج الباب


1. افتح باب الفرن تماما.
  2. قم بتثبيت المفصلتين اليسرى واليمنى بخابور التأمين.
- ملاحظة:** يجب إدخال خوابير التأمين في تجاويف المفصلات تماما.



3. ارفع الجزء السفلي للزجاج الداخلي بعض الشيء إلى أن تنفك خوابير التثبيت من موضع التثبيت (1).
4. ارفع الجزء العلوي للزجاج الداخلي بحرص إلى أن تنفك خوابير التثبيت من موضع التثبيت (2).

#### تنبيه!

عند رفع الزجاج الداخلي قد يظل الزجاج الأوسط ملتصقا بالزجاج الداخلي. تأكد أن الزجاج الأوسط لن يسقط.



5. اخلع الزجاج الداخلي.

قم بتنظيف الألواح الزجاجية باستخدام منظف زجاج وفوطة ناعمة.

#### ⚠ تحذير - خطر الإصابة!


خدوش زجاج باب الجهاز قد تتطور إلى تشققات. لا تستخدم كاشطة زجاج أو مواد تنظيف خشنة أو مسببة للتآكل.

## القضبان

### فك شبكات قضبان التعليق

كل شبكة من شبكات قضبان التعليق مثبتة على ثلاث نقاط على الجدارين الجانبيين داخل حيز الطهي.

1. أمسك شبكة قضبان التعليق من الأمام واسحبها إلى منتصف حيز الطهي.
2. فينك الخطاف الأمامي لشبكة قضبان التعليق من التجويف.
3. افتح شبكة قضبان التعليق بشكل أوسع، واسحبها من التجاويف الخلفية للجدار الجانبي.
4. أمسك البطانة الحفازة لحيز الطهي.
4. أخرج شبكات قضبان التعليق من حيز الطهي.



### تركيب شبكات قضبان التعليق

1. أمسك البطانة الحفازة لحيز الطهي.
2. أدخل خطافات شبكة قضبان التعليق في التجاويف الخلفية للجدار الجانبي.
3. اضغط الخطاف الأمامي لشبكة قضبان التعليق في التجويف.

| النطاق                                                        | التنظيف                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| شعلات غاز<br>موضع الطهي                                       | اخلع طاسات وأغطية الشعلات وقم بتنظيفها باستخدام محلول صابوني. ويجب دائماً أن تكون فتحات تدفق الغاز خالية. شمعات الإشعال: فرشاة صغيرة ناعمة. لا تعمل شعلات الغاز إلا عندما تكون شمعات الإشعال نظيفة. قم بتجفيف جميع الأجزاء جيداً. وتأكد من تثبيتها بشكل سليم عند إعادة تركيبها. أغطية الشعلات مطلية بطبقة مينا (إيناميل) سوداء. يتغير لونها بمرور الوقت. وليس لذلك أي تأثير على وظيفتها. لا تقم بتنظيف أغطية الشعلات في غسالة الأطباق. |
| الأسطح المطلية<br>بطبقة مينا<br>(إيناميل)<br>(الأسطح الملساء) | محلول صابوني ساخن:<br>قم بالتنظيف بفوطة تنظيف، ثم قم بالتجفيف بعد ذلك باستخدام منديل ناعم. قم بإزالة البقع الجيرية والدهنية وبقع النشا وبياض البيض على الفور. فقد يتكوّن الصدأ تحت هذه البقع. تتوافر لدى خدمة العملاء أو المتاجر المتخصصة منظفات خاصة للاستانلس ستيل تناسب الأسطح الساخنة. ضع طبقة رقيقة من مادة العناية بواسطة فوطة ناعمة.                                                                                            |
| أسطح المينا<br>(الإيناميل)<br>والأسطح ذاتية<br>التنظيف        | تراجع الإرشادات الخاصة بأسطح حيز الطهي الواردة عقب الجدول.                                                                                                                                                                                                                                                                                                                                                                             |
| زجاج الباب                                                    | محلول صابوني ساخن:<br>قم بالتنظيف بفوطة تنظيف، ثم قم بالتجفيف بعد ذلك باستخدام منديل ناعم. لا تستخدم أية كاشطة زجاج أو ليفة تنظيف كاشطة الاستانلس ستيل.                                                                                                                                                                                                                                                                                |
| الغطاء الزجاجي<br>لإضاءة حيز<br>الطهي                         | محلول صابوني ساخن:<br>قم بالتنظيف بفوطة تنظيف، ثم قم بالتجفيف بعد ذلك باستخدام منديل ناعم. في حالة الاتساخ الشديد استخدم منظف الفرن.                                                                                                                                                                                                                                                                                                   |
| إطار إحكام الباب<br>لا تقم بفكه!                              | محلول صابوني ساخن:<br>قم بالتنظيف بفوطة تنظيف. لا تقم بحكه.                                                                                                                                                                                                                                                                                                                                                                            |
| القضبان                                                       | محلول صابوني ساخن:<br>انقعها ثم قم بتنظيفها بفوطة تنظيف أو فرشاة.                                                                                                                                                                                                                                                                                                                                                                      |
| الكماليات                                                     | محلول صابوني ساخن:<br>انقعها ثم قم بتنظيفها بفوطة تنظيف أو فرشاة. في حالة وجود اتساخات شديدة استخدم ليفة تنظيف كاشطة من الاستانلس ستيل.                                                                                                                                                                                                                                                                                                |

## ملاحظات

- تنشأ فروق لونية طفيفة بواجهة الجهاز بسبب استخدام خامات مختلفة مثل الزجاج أو البلاستيك أو المعدن.
- الظلال الموجودة على ألواح الباب والتي تبدو كالخطوط ترجع إلى انعكاسات ناتجة عن إضاءة حيز الطهي.
- يتم تجفيف طبقة المينا (الإيناميل) على درجات حرارة عالية للغاية. وقد يتسبب ذلك في اختلافات لونية طفيفة. وهذا أمر طبيعي ولا يؤثر على عملها.
- حواف الألواح الرفيعة لا يمكن طلائها بطبقة المينا (الإيناميل) بشكل كامل. ونتيجة لذلك، فقد تكون هذه الحواف خشنة. ولا يؤثر ذلك على خصائص الحماية من التآكل.

## أسطح حيز الطهي

الجدار الخلفي والأجزاء الجانبية في حيز الطهي ذاتية التنظيف. ويمكنك معرفة ذلك من خلال خشونة السطح.

أرضية حيز الطهي والسقف مطليان بطبقة مينا، ولها أسطح ملساء.

## تنظيف أسطح المينا (الإيناميل)

قم بتنظيف أسطح المينا (الإيناميل) الملساء باستخدام فوطة تنظيف ومحلول صابوني ساخن أو محلول الخل. وقم بتجفيفه بعد ذلك باستخدام فوطة ناعمة.

امسح البقايا المحترقة من الطعام باستخدام فوطة رطبة ومحلول صابوني. في حالة وجود اتساخات شديدة استخدم ليفة تنظيف كاشطة من الاستانلس ستيل أو منظف أفران.

وبعد التنظيف اترك حيز الطهي مفتوحاً ليجف.

**ملاحظة:** يمكن أن تتسبب بقايا الأطعمة في تكون طبقات بيضاء. هذه الطبقات لا تدعو للقلق وليس لها تأثير على الوظيفة. ويمكنك عند الحاجة إزالة هذه البقايا باستخدام حمض الليمون.

## تنظيف الأسطح ذاتية التنظيف

الأسطح ذاتية التنظيف مغطاة بطبقة من الخزف مسامية مطفاة. يتم امتصاص الرذاذ الناتج عن الخبز والتحمير من خلال هذه الطبقة والتخلص منه، بينما الجهاز مشغل.

إذا أصبح تنظيف الأسطح ذاتية التنظيف غير كاف وظهرت بقع داكنة، فإنه يمكن تنظيفها باستخدام وظيفة التنظيف. يراعى في ذلك البيانات الواردة في الفصل المعني.

## تنبيه!

تجنب استخدام أية منظفات أفران لتنظيف الأسطح ذاتية التنظيف. وإلا فسوف تتعرض الأسطح للضرر. إذا وصلت رغم ذلك منظفات الأفران إلى هذه الأسطح، فقم بمسحها على الفور بالماء وإسفنجة. يرجى ألا تقم بالكشط وألا تستخدم أية مواد تنظيف خادشة.

## المحافظة على نظافة الجهاز

كي لا تتكون اتساخات عنيدة حافظ دائماً على نظافة الجهاز وقم بإزالة الاتساخات على وجه السرعة.

## نصائح

- قم بتنظيف حيز الطهي بعد كل استخدام. وبذلك لا يتسنى للاتساخات أن تحترق.
- قم دائماً بإزالة البقع الجيرية والدهنية وبقع النشا وبياض البيض على الفور.
- استخدم اللوح متعدد الاستخدامات لإعداد الكيك الرطب للغاية.
- استخدم للتحمير أواني مناسبة مثل إناء تحمير.

## تنظيف حيز الطهي

1. قم بصب 0,4 لتر من الماء في منتصف أرضية حيز الطهي.
2. اضبط نوع التسخين .
3. اضبط درجة الحرارة على 50°م باستخدام منظم درجة الحرارة.
4. أوقف تشغيل الجهاز بعد مرور 18 دقيقة.
5. اترك الجهاز يبرد.
6. قم بتنظيف حيز الطهي باستخدام فوطة.



## تحذير - خطر الإصابة بحروق!

يصبح الجهاز ساخناً للغاية. لا تلمس أبداً الأسطح الداخلية لحيز الطهي أو عناصر التسخين وهي ساخنة. احرص دائماً على ترك الجهاز يبرد. وأبعد الأطفال عن الجهاز.

## المنظفات المناسبة

حتى لا تتضرر الأسطح المختلفة بفعل استخدام منظفات غير مناسبة، تراعى التعليمات التالية.

لا تستخدم

مع الموقد

- منظفات الغسل اليدوي للأواني أو منظفات غسالات الأطباق دون تخفيف
- أية مواد كاشطة أو إسفنجات خشنة
- أية منظفات أكالة مثل إسبراي الأفران أو مزيل البقع
- أية أجهزة تنظيف بالضغط العالي أو البخار.

لا تستخدم

مع الفرن

- أية منظفات خشنة أو خادشة
- أية منظفات قوية تحتوي على الكحول
- أية ليفات أو إسفنجات خشنة
- أية أجهزة تنظيف بالضغط العالي أو البخار.

اغسل الفوط الإسفنجية الجديدة جيدًا قبل استخدامها.

### ⚠ تحذير - خطر الإصابة بحروق!

يصبح الجهاز ساخنًا للغاية. لا تلمس أبدًا الأسطح الداخلية لحيز الطهي أو عناصر التسخين وهي ساخنة. احرص دائمًا على ترك الجهاز يبرد. وأبعد الأطفال عن الجهاز.

## تعديل البيانات المضبوطة

تتوفر ثلاث إشارات صوتية مختلفة.

1. اضغط على ④.
2. استخدم الزر + أو الزر - لضبط الدقائق المطلوبة للطهي.

## محو البيانات المضبوطة

تتوفر ثلاث إشارات صوتية مختلفة.

1. اضغط على ④.
2. اضغط على الزر + والزر - في وقت واحد.
3. أطفئ الفرن يدويًا إذا كانت عملية الطهي قيد التقدم.

## إيقاف الإشارة الصوتية

اضغط على الزر "-" لإيقاف الإشارة الصوتية.

تتوقف الإشارة الصوتية أو توماتيكيًا بعد سبع دقائق.

## تغيير الإشارة الصوتية

تتوفر ثلاث إشارات صوتية مختلفة.

1. اضغط على الزرين "+" و "-" معًا.
2. اضغط على الزر ④.
3. تظهر الإشارة الصوتية الحالية في وحدة العرض، مثلًا «النغمة 1». اضغط على الزر "-" لاختيار إشارة صوتية مختلفة.

## المنظفات

العناية الجيدة بجهازك وتنظيفه باهتمام يحافظ على جماله وكفاءته الوظيفية لفترة طويلة. ونوضح لك فيما يلي كيفية العناية بجهازك وتنظيفه بطريقة صحيحة.

### ⚠ تحذير - خطر الصعق الكهربائي!

الرطوبة التي تتوغل في الجهاز قد تتسبب في حدوث صعق كهربائي. لا تستخدم أية أجهزة تنظيف بالضغط العالي أو أجهزة تنظيف البخار.

### ⚠ تحذير - خطر الإصابة بحروق!

يصبح الجهاز ساخنًا للغاية. لا تلمس أبدًا الأسطح الداخلية لحيز الطهي أو عناصر التسخين وهي ساخنة. احرص دائمًا على ترك الجهاز يبرد. وأبعد الأطفال عن الجهاز.

| المنظفات                                                                                                                                                                                                                                                                                                                                          | النطاق                                 |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------|
| محلول صابوني ساخن:<br>قم بالتنظيف بفوطة تنظيف، ثم قم بالتجفيف بعد ذلك باستخدام منديل ناعم. لا تستخدم منظف زجاج أو كاشطة زجاج.                                                                                                                                                                                                                     | الجهاز من الخارج                       |
| محلول صابوني ساخن:<br>قم بالتنظيف بفوطة تنظيف، ثم قم بالتجفيف بعد ذلك باستخدام منديل ناعم.<br>قم بإزالة البقع الجيرية والدهنية وبقع النشا وبياض البيض على الفور. فقد يتكوّن الصدأ تحت هذه البقع.<br>تتوافر لدى خدمة العملاء أو المتاجر المتخصصة منظفات خاصة للاستئناس ستيل تناسب الأسطح الساخنة. ضع طبقة رقيقة من مادة العناية بواسطة فوطة ناعمة. | الواجهة<br>الاستئناس ستيل              |
| منظفات الزجاج:<br>قم بالتنظيف باستخدام منديل ناعم.                                                                                                                                                                                                                                                                                                | الألومنيوم<br>والبلاستيك               |
| محلول صابوني ساخن.<br>استخدم القليل من الماء، حيث لا يجوز أن يتوغل الماء داخل الجهاز عبر الأجزاء السفلية للشعلات. احرص على إزالة المواد المنسكبة وبقايا الأطعمة المطهية على الفور.<br>يمكنك فك قاعدة الأواني. لا تقم بتنظيف قاعدة الأواني في غسالة الأطباق.                                                                                       | موضع الطهي<br>الغازي وقاعدة<br>الأواني |

## وظائف الوقت

### ضبط الوقت

**ملاحظة:** إذا لم يتم ضبط الوقت، فلن يعمل الفرن.

عند الاستخدام لأول مرة، أو بعد انقطاع الكهرباء، تومض الأرقام ⑤ في وحدة العرض.

4. اضغط على ⑤.
- يظهر النص End (انتهاء) في وحدة العرض على التوالي مع مدة الطهي المضبوطة مسبقاً والمضافة إلى الوقت الحالي (يظهر في وحدة العرض وقت انتهاء الطهي الحالي). (مثل 18:30).
5. استخدم الزر + أو الزر - لضبط وقت انتهاء جديد للطهي (مثل 19:30).
- ملاحظة:** يجب مراعاة إضافة الدقائق المعدودة لإحماء الفرن إلى مدة الطهي.
6. انتظر 5 ثوان دون الضغط على أي مفتاح لكي تعمل الوظيفة.
- يظهر الوقت الحالي والرمز A في وحدة العرض.
7. اختر إحدى الوظائف ودرجة حرارة الطهي.
8. يختفي الرمز ⑤ من وحدة العرض. لن تبدأ عملية الطهي حتى بلوغ الوقت المخطط (مثل 18:30)، وهذا هو الفارق بين مدة انتهاء الطهي ومدة الطهي. اضغط على الزر + والزر - في نفس الوقت لإرجاع ضبط البرنامج المضبوط.
9. عند اكتمال الطهي، تصدر إشارة صوتية مسموعة (صافرة).
10. لإيقاف الصافرة، ما عليك سوى الضغط على أي مفتاح في ساعة المبرمج.
11. أعد طارة الوظيفة ودرجة الحرارة إلى الوضع 0.
12. اضغط على ⑤ لإرجاع ضبط ساعة المبرمج.

### ملاحظات

- تتوقف فعالية عناصر التسخين في نهاية الطهي. في وحدة العرض، ينطفئ ⑤ ويومض الرمز A وتصدر صافرة.
- لا يمكن ضبط مدة طهي تزيد عن 10 ساعات.
- لا يمكن ضبط مدة طهي مبرمجة تزيد عن 24 ساعة.
- لإرجاع ضبط البرنامج المضبوط، اضغط على + و - في وقت واحد.
- لعرض مدة الطهي المتبقية بعد الضبط، اضغط على ⑤ لمدة ثانيتين.
- اضغط على ⑤ مرة أخرى. يظهر في وحدة العرض النص dur (مدة) ومدة الطهي المتبقية على التوالي.

### ضبط مقياتي منبه الدقائق

لا يقوم مقياتي منبه الدقائق بإيقاف عملية الطهي، وإنما يبلغ المستخدم بميعاد انقضاء الوقت المضبوط.

ويمكن تفعيل مقياتي منبه الدقائق في أي وقت.

1. اضغط على ⑤ لمدة ثانيتين.
- يظهر في وحدة العرض الأرقام 0.00 ويومض ⑤ بين الساعات والدقائق.
2. استخدم الزر + أو الزر - لضبط الدقائق المطلوبة للطهي.
3. انتظر 5 ثوان دون الضغط على أي مفتاح لكي تعمل الوظيفة.
- يظهر الوقت الحالي والرموز ⑤ و ⑤ في وحدة العرض.
- تصدر صافرة عند بلوغ الوقت المضبوط.

4. لإيقاف الصافرة، ما عليك سوى الضغط على أي مفتاح في ساعة المبرمج.
5. اضغط على ⑤ لإرجاع ضبط ساعة المبرمج.

**ملاحظة:** يمكن ضبط مقياتي منبه المقياتي من 1 دقيقة إلى 23 ساعة و 59 دقيقة كحد أقصى.

### ملاحظات


- تتوقف فعالية عناصر التسخين في نهاية الطهي. في وحدة العرض، ينطفئ ⑤ ويومض الرمز A وتصدر صافرة.
- لا يمكن ضبط مدة طهي تزيد عن 10 ساعات.
- لإرجاع ضبط البرنامج المضبوط، اضغط على + و - في وقت واحد.
- لعرض مدة الطهي المتبقية بعد الضبط، اضغط على ⑤ لمدة ثانيتين.
- اضغط على ⑤ مرة أخرى. يظهر في وحدة العرض النص dur (مدة) ومدة الطهي المتبقية على التوالي.

### ضبط الطهي المبرمج


الطهي المبرمج عبارة عن وظيفة تسمح للمستخدم بضبط المدة وتحديد الوقت الذي تنتهي عنده عملية الطهي أوتوماتيكياً.

1. اضغط على ⑤ حتى يظهر ⑤.
2. اضغط على ⑤ مرة أخرى.
- يظهر في وحدة العرض الأرقام 0.00 والنص dur (مدة) على التوالي، ويومض الرمز A (على سبيل المثال الوقت الحالي 17:30).
3. استخدم الزر + أو الزر - لضبط الدقائق المطلوبة للطهي (على سبيل المثال 1 ساعة).


## 1. قم بتركيب هيكل السيخ الدوار في الجلب المطلوبة



## 2. قم بتركيب السيخ الدوار على هيكل السيخ الدوار وقم بفك المقبض.



## 3. أدخل اللوح متعدد الاستخدامات في مستوى الإدخال 1 وأدخل السيخ الدوار في مرتكز المحرك.



## 4. أغلق باب الجهاز.

## تشغيل طريقة السيخ الدوار

**ملاحظة:** قم بإحماء الفرن عند استخدام السيخ الدوار مع نوع التسخين [A]. ولا تقم بضبط نوع التسخين [B] إلا بعد إدخال السيخ الدوار.

## 1. أدر طارة استعمال الفرن إلى الوضع [A].

## 2. اضبط درجة الحرارة.

**ملاحظة:** أضف بعض الماء في اللوح متعدد الاستخدامات، لتجميع الدهون المتقاطرة.

## إخراج السيخ الدوار

## ⚠ تحذير - خطر الإصابة بحروق!

لا تلمس أبداً أسطح حيز الطهي أو عناصر التسخين وهي ساخنة. أبعد الأطفال دائماً عن الجهاز. افتح باب الجهاز بحرص. ربما يتسرب بخار ساخن.

## 1. افتح باب الجهاز

## 2. اسحب اللوح متعدد الاستخدامات حتى المنتصف ببطء لإخراجه من حيز الطهي.

## 3. أخرج اللوح متعدد الاستخدامات تماماً من حيز الطهي وضعه على سطح العمل.

## 4. اربط المقبض وأخرج سيخ الشواء من هيكل سيخ الشواء.

## الفرن

## استعمال الفرن

## تشغيل الفرن

**ملاحظة:** احتفظ بباب الجهاز مغلقاً دائماً أثناء التشغيل.

## 1. اضبط مفتاح اختيار الوظائف على طريقة التشغيل المرغوبة.

## 2. اضبط مفتاح اختيار درجة الحرارة على درجة الحرارة المرغوبة. يتم تشغيل الفرن.

تضيء لمبة البيان أثناء قيام الفرن بالتسخين. وتنطفئ خلال فترات التوقف عن التسخين.

**ملاحظة:** تضيء لمبة البيان أيضاً عندما يكون مفتاح اختيار الوظيفة على وضع الصففر وهناك درجة حرارة مضبوطة. لا يبدأ فرن الطهي في عملية التسخين إلا بعد ضبط طريقة تشغيل.

## إيقاف الفرن


## 1. اضبط مفتاح اختيار الوظيفة على الوضع O.

## 2. اضبط مفتاح اختيار درجة الحرارة على الوضع O. يتم إطفاء الفرن.

## السيخ الدوار

## تحضير السيخ الدوار


## 1. قم بتركيب مشبك تثبيت على السيخ الدوار واربط المقبض.



## 2. ضع قطع اللحم في منتصف السيخ الدوار قدر الإمكان.

## 3. قم بتثبيت قطع اللحم بواسطة مشابك التثبيت.

## 4. قم بتأمين مشابك التثبيت بواسطة البراغي محزنة الرأس.



## تركيب السيخ الدوار

## ⚠ تحذير - خطر الإصابة بحروق!

لا تلمس أبداً أسطح حيز الطهي أو عناصر التسخين وهي ساخنة. أبعد الأطفال دائماً عن الجهاز. افتح باب الجهاز بحرص. ربما يتسرب بخار ساخن.

## استعمال الجهاز

لقد تعرفت بالفعل على عناصر الاستعمال وطريقة استخدامها. والآن نشرح لك كيفية ضبط جهازك. فسوف تتعرف على ما يحدث عند التشغيل والإيقاف وكيفية ضبط طرق التشغيل.

### الموقد

#### تشغيل شعلات الغاز

##### ملاحظات

- لا يجوز تشغيل الأجهزة المزودة بغطاء إلا والغطاء مفتوح.
- يجب أن تكون أغطية الشعلات مستقرة دائماً فوق طاسات الشعلات بالضبط. ويجب أن تكون الفتحات الموجودة بطاسة الشعلة خالية تماماً. كما يجب أن تكون جميع الأجزاء جافة.
- يراعى ألا يصدر باتجاه موضع الطهي تيار هواء مباشر من مكيفات الهواء أو المراوح أو ما شابه.

1. اضغط طارة استعمال موضع الطهي المرغوب وأدرها إلى الوضع ⑤. يتم إشعال شعلة الغاز.
2. احتفظ بطارة الاستعمال مضغوطة لبضع ثوانٍ إلى أن يتجانس اللهب.
3. اضبط القدرة المرغوبة.

| الوضع | المعنى                  |
|-------|-------------------------|
| ⑤     | اللهب الموفر، أدنى قدرة |
| ⑤     | اللهب الكبير، أعلى قدرة |

لا يكون اللهب متجانساً ما بين الوضعين ⑤ و ⑤. اختر دائماً وضعاً ما بين ⑤ و ⑤.

#### عند انطفاء اللهب مرة أخرى

اضبط طارة الاستعمال على وضع الإطفاء. انتظر لمدة دقيقة ثم كرر عملية التشغيل.

#### ⚠ تحذير - خطر الحريق!

يتسرب الغاز عند انطفاء اللهب. فلا تترك شعلة الغاز دون مراقبة أثناء التشغيل. يراعى ألا يكون هناك تيار هواء.

#### ⚠ تحذير - خطر الحريق المفاجئ!

إذا لم تشتعل الشعلة بعد 15 ثانية، اضبط طارة الاستعمال على وضع الإيقاف وافتح الباب أو النافذة الموجودة بالمكان. انتظر لمدة دقيقة على الأقل قبل إشعال الشعلة من جديد.


#### في حالة عدم اشتعال شعلة الغاز

في حالة انقطاع التيار الكهربائي أو وجود رطوبة على شمعات الإشعال يمكنك إشعال شعلات الغاز بولاعة غاز أو بعود ثقاب.

#### إطفاء شعلات الغاز

أدر طارة استعمال موضع الطهي المرغوب إلى الوضع ⑤

## تنظيف أغطية وطاسات الشعلات




1. قم بتنظيف أغطية الشعلات (A) وطاسات الشعلات (B) بالماء ومادة تنظيف.
2. قم بتجفيف الأجزاء جيداً.
3. قم بتركيب طاسة الشعلة (B) على موضع الطهي (C).
4. قم بتركيب غطاء الشعلة (A) بدقة على طاسة الشعلة (B).

### تنظيف الكماليات

قبل استخدام الكماليات قم بتنظيفها جيداً بمحلول صابوني دافئ وفوطة تنظيف.

### تركيب الجلب الملولبة للسخن الدوار

1. قم بتركيب الجلب الملولبة من أعلى في ثقب الأركان الأربعة للوح متعدد الاستخدامات.
2. قم بتثبيت الصواميل الحلقية بالجهة السفلية المقابلة.
3. أحكم ربط الجلب الملولبة بواسطة مفك.



### تركيب طقم الحوامل التلسكوبية

تجد الإرشادات الخاصة بتركيب طقم الحوامل التلسكوبية في الطقم الموجود بمجموعة التجهيزات.

## قبل الاستخدام لأول مرة

ستتعرف هنا على ما يجب القيام به قبل استخدام الفرن أو الموقد الخاص بك في إعداد الطعام للمرة الأولى. اقرأ أولاً الفصل التالي. «إرشادات الأمان المهمة» في صفحة 4

قم بإزالة مواد التغليف عن الجهاز وتخلص منها بطريقة سليمة.

### ضبط الوقت

**ملاحظة:** إذا لم يتم ضبط الوقت، فلن يعمل الفرن.

عند الاستخدام لأول مرة، أو بعد انقطاع الكهرباء، تومض الأرقام ① في وحدة العرض.

1. اضغط على ① لمدة ثانيتين.  
تومض النقطة بين الساعات والدقائق.
  2. استخدم الزر + أو - لضبط الساعة.
  3. **ملاحظة:** احتفظ بالزر مضغوطاً للزيادة أو التقليل بسرعة.  
انتظر 7 ثوان.
- توقف النقطة بين الساعات والدقائق عن الوميض. يتم اعتماد الوقت الذي تم ضبطه.

**ملاحظة:** لتغيير الوقت المضبوط، اضغط على الزر + والزر - في وقت واحد لمدة ثانيتين، ثم اضبط الوقت الحالي باستخدام الزر + والزر -.

### تسخين الفرن

#### التنظيف المسبق للفرن

1. أخرج الكماليات وشبكة قضبان التعليق من حيز الطهي.
2. قم بإزالة بقايا مواد التغليف، مثل جزيئات البوليستيرين، من حيز الطهي تماماً.
3. بعض الأجزاء مغطاة برقاقة حماية. قم بإزالة رقاقة الحماية.
4. قم بتنظيف الجهاز من الخارج بمندبل ناعم رطب.
5. قم بتنظيف حيز الطهي بمحلول صابوني ساخن.

#### تسخين الفرن


للتخلص من الروائح غير المستحبة للأشياء الجديدة، قم بتسخين الفرن وهو مغلق وفارغ.

1. أدر مفتاح اختيار درجة الحرارة على درجة الحرارة القصوى.
2. قم بإطفاء الفرن بعد 45 دقيقة.

#### التنظيف اللاحق للفرن

1. قم بتنظيف حيز الطهي بمحلول صابوني ساخن.
2. قم بتركيب شبكات قضبان التعليق.



المثال في الصورة: اللوح متعدد الاستخدامات



### الكماليات الخاصة



يمكنك لاحقاً شراء الكماليات من خدمة العملاء.

| الكماليات                                 | الشرح                                                                                                                                                                                                                       |
|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| لوح الخبز المطلي بطبقة المينا (الإيناميل) | للكيك الذي يتم إعداده على لوح والمخبوزات الصغيرة.<br>رقم خدمة العملاء: 11012235                                                                                                                                             |
| اللوحة متعددة الاستخدامات                 | للكيك الرطب والمخبوزات والوجبات المجمدة وقطع اللحم الكبيرة.<br>يمكن استخدام اللوحة متعددة الاستخدامات كوعاء لتجميع الدهون المتساقطة عندما تقوم بالشواء بشكل مباشر على الشبكة السلكية.<br>رقم خدمة العملاء: 11012236         |
| شبكة الخبز والشواء                        | للأواني وصواني الكيك وقطع اللحم والأطعمة المشوية والوجبات المجمدة.<br>رقم خدمة العملاء: 11012237                                                                                                                            |
| حلقة مقلاة ووك                            | قاعدة لمقلاة الووك، توضع على شعلة مقالي الووك.<br>عند استخدام قاعدة مقالي الووك يمكن استخدام أواني طهي ذات قطر يزيد على 26 سم (مقلاة الووك، مقالي تحمير، جِل، أوعية ذات قيعان محدبة، وخلافه).<br>رقم خدمة العملاء: 00745721 |
| طقم حوامل تلسكوبية                        | طقم حوامل تلسكوبية لمستوى واحد.<br>رقم خدمة العملاء: 12006236                                                                                                                                                               |
| منظم ضغط الغاز                            | منظم ضغط الغاز عند التشغيل بالغاز المسال.<br>بالنسبة لعمان: صامولة توصيل أسطوانة غاز مقاس 27 مم (ارتفاع 14 مم) - فوهة داخلية 12,5 مم<br>رقم خدمة العملاء: 752313                                                            |
| منظم ضغط الغاز                            | منظم ضغط الغاز عند التشغيل بالغاز المسال.<br>بالنسبة للإمارات/اليمن: صامولة توصيل أسطوانة غاز مقاس 25 مم (ارتفاع 16 مم) - فوهة داخلية 10 مم<br>رقم خدمة العملاء: 618228                                                     |




## الكماليات

مرفق بجهازك كماليات متعددة. تحصل هنا على نظرة عامة عن الكماليات المرفقة واستخدامها الصحيح.


| الكماليات                                                                             | الشرح                                                                                                                                                                                                                  |
|---------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <b>شبكة الخبيز والشواء</b><br>للأواني وصواني الكيك وقطع اللحم والأطعمة المشوية والوجبات المجمدة.                                                                                                                       |
|    | <b>اللوحة متعددة الاستخدامات</b><br>للكيك الرطب والمخبوزات والوجبات المجمدة وقطع اللحم الكبيرة. يمكن استخدام اللوحة متعددة الاستخدامات كوعاء لتجميع الدهون المتساقطة عندما تقوم بالشواء بشكل مباشر على الشبكة السلكية. |
|    | <b>قاعدة الإسبريسو</b><br>قاعدة لكنتة إسبريسو، توضع على الشعلة الموفرة.                                                                                                                                                |
|    | <b>السيخ الدوار</b><br>مع حامل للسيخ الدوار لقطع اللحم والطيور كبيرة الحجم. يُستخدم فقط بالاشتراك مع اللوحة متعددة الاستخدامات.                                                                                        |
|  | <b>خوابير التأمين</b><br>لتثبيت المفصلات.                                                                                                                                                                              |
|  | <b>طقم حوامل تلسكوبية</b><br>باستخدام القضبان القابلة للإخراج يمكن إخراج الكماليات تماما.                                                                                                                              |

يمكن إدخال لوح الخبيز وشبكة الخبيز والشواء في حيز الطهي على 5 مستويات ارتفاع مختلفة. احرص دائما على إدخال الكماليات حتى النهاية حتى لا تلامس زجاج الباب. يراعى دائما إدخال الكماليات في حيز الطهي بشكل صحيح.



### طقم حوامل تلسكوبية

باستخدام القضبان القابلة للإخراج يمكن إخراج الكماليات تماما. يراعى عند تركيب مبيت لوح الخبيز وشبكة الشواء أن يكون المبيت مستقرا أمام حز القضبان القابلة للإخراج.



**ملاحظة:** يجب تركيب السيخ الدوار في المستوى 1. في هذه الحالة قم بتركيب القضبان القابلة للإخراج في المستويات العلوية الأربعة للوح الخبيز وشبكة الخبيز والشواء.


### ⚠ تحذير - خطر الحريق!

لا يجوز بأي حال من الأحوال وضع لوح خبيز أو مقلاة أو أي وعاء طهي آخر على أرضية الفرن بشكل مباشر. حيث إن ذلك يؤدي إلى فرط سخونة أرضية الجهاز ويمكن أن يلحق ضررا بالغا بالجهاز.

### وظيفة التثبيت

من الممكن إخراج الكماليات إلى نصف المسافة تقريبا حتى تثبت في مكانها. تمنع وظيفة التثبيت انقلاب الكماليات عند سحبها للخارج. ويجب إدخال الكماليات في حيز الطهي بطريقة صحيحة حتى تعمل خاصية الحماية من الانقلاب بشكل سليم.

تأكد عند إدخال الشبكة السلكية أن طرف التثبيت **a** بالخلف ويشير إلى أسفل. يجب أن يكون الجانب المفتوح موجهاً لباب الجهاز والتقوس موجهاً لأسفل.



تأكد عند إدخال الألواح أن طرف التثبيت **a** بالخلف ويشير إلى أسفل. يجب أن تكون الحافة المائلة للكماليات **b** في الأمام في مواجهة باب الجهاز.

| نوع التسخين          | الاستخدام                                                                                                                                      |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| الشواية الكبيرة      | لشواء الأطعمة المفرودة مثل الاستيك أو السجق (النقانق) أو التوست أو للتحمير. ويسخن السطح بالكامل أسفل جسم تسخين الشواية.                        |
| الشواية/السيخ الدوار | الشواية: لوجبة الفرد الواحد أو الكميات الصغيرة من قطع الاستيك والسجق (النقانق) والسمك والتوست. السرخ الدوار: لقطع اللحم، اللحم الملفوف والطيور |

### مفتاح اختيار درجة الحرارة

يمكنك ضبط درجة الحرارة باستخدام مفتاح اختيار درجة الحرارة.

| الوضع    | المعنى               |
|----------|----------------------|
| ○        | إطفاء                |
| 260 - 50 | نطاق درجة الحرارة °م |

يوجد مصدر بين الوضعين 260 و 0. فلا تقم بإدارة الطارة متجاوزًا المصدر.

**ملاحظة:** لإذابة التجمد اضبط مفتاح اختيار الوظيفة على  ومفتاح اختيار درجة الحرارة على 0.


### مروحة التبريد

يخرج الهواء الساخن من فتحة التهوية. يتم تشغيل وإيقاف مروحة التبريد عند الحاجة. تنبيه! لا تقم بتغطية فتحات التهوية. وإلا فسوف يتعرض الفرن لفرط السخونة.

حتى يتم تبريد حيز الطهي بشكل أسرع بعد التشغيل، يستمر تشغيل مروحة التبريد لفترة معينة.

### درج الحفظ

افتح درج الحفظ من خلال طي اللوح لأسفل.



يمكنك الاحتفاظ بكماليات سطح الموقد أو الفرن في هذا الدرج.

**⚠ تحذير - خطر الحريق!**

لا تحتفظ أبدًا بأشياء قابلة للاشتعال في درج الحفظ.

### طارات استعمال مواضع الطهي

يمكنك باستخدام طارات الاستعمال هذه ضبط قدرة تسخين شعلات غاز مواضع الطهي.

وتبين لك الرموز بأعلى طارات الاستعمال شعلة الغاز المعنية.

| الوضع | المعنى                  |
|-------|-------------------------|
| ○     | إطفاء                   |
| 🔥     | اللهب الكبير، أعلى قدرة |
| 🔥     | اللهب الموفر، أدنى قدرة |

### الفرن

لاستخدام الفرن تحتاج إلى طارتي استعمال. مفتاح اختيار الوظيفة ومفتاح اختيار درجة الحرارة.

### طارة استعمال الفرن










#### مفتاح اختيار الوظيفة

يمكنك ضبط نوع التسخين باستخدام مفتاح اختيار الوظيفة.

| نوع التسخين                    | الاستخدام                                                                                                                                                                |
|--------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| الهواء الساخن                  | للخبيز والطهي على مستوى واحد أو أكثر. وتقوم المروحة بتوزيع سخونة جسم التسخين الحلقي بالجدار الخلفي في حيز الطهي بالتساوي.                                                |
| اقتصادي Eco                    | للطهي الموفر في الطاقة للأطعمة المختارة. وتنبعث السخونة من أعلى ومن أسفل بالتساوي.                                                                                       |
| التسخين العلوي/السفلي والمروحة | للكيك المشرب تمامًا بالعصير. وتنبعث السخونة من أعلى ومن أسفل بالتساوي. وتقوم المروحة بتوزيع الهواء الساخن حول الطعام.                                                    |
| التسخين العلوي/السفلي          | للخبيز والتحمير التقليديين على مستوى واحد. مناسب خصيصًا للكيك ذي الطبقة العلوية الرطبة. وتنبعث السخونة من أعلى ومن أسفل بالتساوي.                                        |
| التسخين السفلي والمروحة        | للمرحلة النهائية لإعداد المخبوزات، مثل كيك الفواكه الرطب، وللحفظ وللوجبات التي تطهى في حمام مائي. وتنبعث السخونة من أسفل. وتقوم المروحة بتوزيع الهواء الساخن حول الطعام. |
| شواية بتدوير الهواء            | لشواء الطيور والأسماك الكاملة وقطع اللحم الكبيرة. ويسخن السطح بالكامل أسفل جسم تسخين الشواية. وتقوم المروحة بتوزيع الهواء الساخن حول الطعام.                             |

## إرشادات الاستخدام

ستساعدك الإرشادات التالية على توفير الطاقة وتجنب إلحاق أضرار بأواني الطهي:

|                                                                                                                                                                   |                                                                                     |                                                                                    |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
| استخدم أواني طهي بمقاس مناسب للشعلة المعنية.<br>لا تستخدم أواني طهي صغيرة على الشعلات الكبيرة. ينبغي ألا يلمس اللهب جوانب أواني الطهي.                            |    |   |
| لا تستخدم أواني طهي مشوهة لا تستقر على الموقد إذا ما وضعت عليه. فقد تنقلب هذه الأواني. اقتصر على استخدام أواني طهي بقاعدة مسطحة وسميكة.                           |    |   |
| لا تطهو بدون غطاء أو إذا تحرك الغطاء عن الإناء. حيث يؤدي ذلك إلى إهدار قدر كبير من الطاقة.                                                                        |    |   |
| ضع إناء الطهي على منتصف الشعلة وإلا فيمكن أن ينقلب الإناء. لا تضع الأواني الكبيرة على الشعلات بالقرب من عناصر الاستعمال. فقد تتعرض للضرر من جراء السخونة المفرطة. |    |   |
| ضع الأواني على قواعد الأواني، لا على الشعلات مباشرة. تحقق قبل الاستعمال من أن قواعد الأواني وأغطية شعلات الغاز موضوعة بشكل صحيح.                                  |   |  |
| تعامل بحذر مع الأواني الموضوعة على الموقد. لا تطرق على الموقد ولا تضع عليه أوزاناً ثقيلة.                                                                         |  |                                                                                    |
| لا تستخدم شعلتان أو عدة مصادر حرارية لإناء طهي واحد. تجنب استخدام مقالي التحمير والأوعية الخزفية وخلافه لفترة طويلة مع القدرة القصوى.                             |  |                                                                                    |

## الساعة الإلكترونية

يمكنك ضبط المدة باستخدام الساعة الإلكترونية.

بعد انقضاء المدة الزمنية تصدر إشارة صوتية.

الأزرار الوظيفية للساعة الإلكترونية


| الرمز | المعنى             | الاستخدام            |
|-------|--------------------|----------------------|
| ⌚     | الساعة الإلكترونية | ضبط المدة أو الوقت   |
| -     | ناقص               | تقليل المدة أو الوقت |
| +     | زائد               | زيادة المدة أو الوقت |

## سطح الموقد

**⚠ تحذير - خطر الإصابة بحروق!**

يتدفق هواء ساخن من فتحة التهوية الموجودة بسطح الموقد. لا تلمس فتحة التهوية أبداً.

مع الأجهزة المزودة بغطاء، يراعى أنه لا يجوز أيضاً تشغيل شعلات الفرن إلا والغطاء مفتوح.




## الشرح

|   |                              |
|---|------------------------------|
| 1 | الشعلة القوية (2,9 كيلوواط)  |
| 2 | شعلة مقلاة ووك (4 كيلوواط)   |
| 3 | الشعلة العادية (1,8 كيلوواط) |
| 4 | فتحة التهوية                 |
| 5 | الشعلة الموفرة (1,0 كيلوواط) |

## أنواع شعلات الغاز

| شعلات الغاز    | قطر الإناء/المقلاة |
|----------------|--------------------|
| الشعلة الموفرة | 12 - 14 سم         |
| الشعلة العادية | 16 - 22 سم         |
| الشعلة القوية  | 18 - 26 سم         |
| شعلة مقالي ووك | 18 - 26 سم         |




| الشرح |                |
|-------|----------------|
| 1     | الغطاء         |
| 2     | سطح الموقد     |
| 3     | لوحة الاستعمال |
| 4     | الفرن          |
| 5     | درج الحفظ      |

## التعرف على الجهاز

تتعرف هنا على جهازك الجديد. كما تجد هنا معلومات حول لوحة الاستعمال وسطح الموقد والفرن وأنواع التسخين والكماليات. من الوارد أن تكون هناك بعض الاختلافات في التفاصيل حسب موديل الجهاز.

## لوحة الاستعمال



| الشرح |                               |
|-------|-------------------------------|
| 1     | الساعة الإلكترونية            |
| 2     | طارة استعمال درجة حرارة الفرن |
| 3     | لمبة بيان فرن الطهي           |
| 4     | طارة استعمال وظائف الفرن      |
| 5     | طارات استعمال مواضع الطهي     |

## حماية البيئة

### الفرن

#### تنبيه!

- الكماليات أو الرقائق أو ورق إعداد المخبوزات أو الأواني على أرضية حيز الطهي: لا تضع أية كماليات على أرضية حيز الطهي. لا تقم بتغطية أرضية حيز الطهي بأي نوع من رقائق الألومنيوم أو ورق المخبوزات. لا تضع أية أواني على أرضية حيز الطهي. حيث إن ذلك يؤدي إلى تراكم السخونة. كما أن أزمدة إعداد المخبوزات والتحمير لن تكون صحيحة، وسوف يتسبب ذلك في إلحاق الضرر بطبقة المينا (الإيناميل).
- إدخال الكماليات: حسب طراز الجهاز قد تتسبب الكماليات في خدش زجاج الباب عند غلق باب الجهاز. فاحرص دائماً على إدخال الكماليات في حيز الطهي حتى النهاية.
- الماء في حيز الطهي الساخن: لا تقم أبداً بصب الماء في حيز الطهي الساخن. حيث إن ذلك يؤدي إلى توليد بخار ماء. كما أن تغير درجة الحرارة قد يلحق أضراراً بطبقة المينا (الإيناميل).
- الأطعمة الرطبة: لا تحتفظ بأطعمة رطبة في حيز الطهي وهو مغلق لفترات طويلة. فسوف يتسبب ذلك في إلحاق الضرر بطبقة المينا (الإيناميل).
- عصارة الفاكهة: عند إعداد الفطائر التي تحتوي على عصارة فاكهة بكمية كبيرة، لا تقم بملء لوح الخبز بشكل زائد عن الحد. فعصارة الفاكهة التي تتقاطر من لوح الخبز تترك بقعاً يتعذر إزالتها. استخدم اللوح متعدد الاستخدامات قدر المستطاع، فهو أكثر عمقا.
- التبريد بينما باب الجهاز مفتوح: لا تقم بتبريد حيز الطهي إلا وهو مغلق. ويراعى أن باب الجهاز إذا كان مفتوحاً ولو بمقدار بسيط فقط، فإن واجهات الوحدات المجاورة يمكن أن تتضرر بمرور الوقت.
- إطار إحكام غلق الفرن المتسخ بشدة: إذا كان إطار إحكام غلق الفرن متسخاً بشدة، فإن باب الفرن لن ينغلق بشكل صحيح والفرن مشغل. وقد تلحق أضرار بواجهات الوحدات المجاورة. لذلك يجب المحافظة دائماً على نظافة إطار إحكام غلق الفرن.
- باب الفرن كسطح ارتكاز: لا تضع شيئاً على باب الفرن المفتوح أو ترتكز عليه. ولا تقم بتعليق أية أشياء على باب الفرن.
- نقل الجهاز: لا تحمل الجهاز أو تمسكه من مقبض الباب. فمقبض الباب لا يستطيع أن يتحمل وزن الجهاز، وقد ينكسر نتيجة لذلك.
- الكماليات الثقيلة: لا تسحب الكماليات المُنقلة بالطعام للخارج بدرجة كبيرة دون تخفيف الحمل عنها. فالكماليات الثقيلة يمكن أن تنقلب عند سحبها للخارج. كما ينشأ ضغط على حوز حيز الطهي يؤدي إلى الإضرار بطبقة المينا (الإيناميل). قم بتخفيف الحمل الواقع على الكماليات أثناء سحبها للخارج من خلال سندها بيدك قليلاً.
- تنبيه! استخدم دائماً فوطة أواني مع الكماليات الساخنة.

جهازك الجديد ذو فعالية وكفاءة خاصة في استهلاك الطاقة. تجد هنا نصائح حول كيفية التعامل مع جهازك والتوفير في الطاقة وكيفية التخلص من الجهاز بطريقة سليمة.

### توفير الطاقة عند استخدام الفرن

- لا تقم بإحماء الفرن إلا إذا كان ذلك مقرراً في وصفة الطهي أو منصوصاً عليه في جداول دليل الاستعمال.
- استخدم صواني الخبز القاتمة أو المطلية بطبقة سوداء أو طبقة المينا (الإيناميل). فهي تمتص الحرارة بصورة جيدة للغاية.
- لا تفتح باب الفرن أثناء الطهي أو إعداد المخبوزات أو الشواء إلا في أضيق الحدود.
- من الأفضل خبز العديد من الفطائر الواحدة بعد الأخرى. حيث يظل الفرن محتفظاً بسخونته. وبذلك يقل الوقت اللازم لإعداد المخبوزات بالنسبة للفطيرة الثانية. كما يمكنك أيضاً وضع صينيتين متجاورتين. بالنسبة لأوقات الطهي الطويلة نسبياً يمكنك إطفاء الفرن قبل نهاية زمن الطهي بعشر دقائق، واستخدام الحرارة المتبقية لإنهاء الطهي.

### توفير الطاقة عند استخدام الموقد

- يراعى دائماً اختيار الإناء الأنسب حجماً للأطعمة. إذ أن الإناء الكبير المملوء بكمية قليلة فقط يستهلك قدرًا كبيراً من الطاقة.
- أغلق الإناء دائماً بغطاء مناسب.
- قم في الوقت المناسب بالانتقال إلى درجة طهي أدنى.
- يجب أن يكون لهب الغاز ملائماً لقاعدة الإناء بصفة دائمة.

### التخلص من المخلفات بطريقة لا تضر بالبيئة

تخلص من مواد التغليف بطريقة لا تضر بالبيئة.

هذا الجهاز مميز طبقاً للمواصفة الأوروبية 2012/19/EU فيما يتعلق بالأجهزة الكهربائية والإلكترونية القديمة (waste electrical and electronic equipment - WEEE). وتحدد هذه المواصفة الإطار العام الساري داخل دول الاتحاد الأوروبي لعملية استرداد الأجهزة القديمة وإعادة استغلالها.



## أسباب الأضرار


### الموقد

#### تنبيه!

- لا تستخدم مواضع الطهي في حالة عدم وضع أواني عليها. ولا تقم بتسخين أواني أو مقالي فارغة. حيث إن ذلك سوف يلحق الضرر بقاعدة الإناء.
- احرص على إزالة المواد المنسكبة على الفور. واستخدم أواني عميقة للأطعمة التي بها كمية كبيرة من السوائل. وبذلك تضمن عدم فوران السوائل وانسكابها.
- لا تستخدم صواني تحمير يلزم تسخينها على شعلتين. حيث إن ذلك يؤدي إلى تراكم السخونة. وقد تلحق أضرار بالجهاز.
- عند الطهي على مواضع الطهي الغازية تنبعث بشكل إضافي سخونة ورطوبة. وقد يلحق الضرر بوحدات أثاث المطبخ المجاورة بمرور الوقت. وفي حالة استمرار الطهي لمدة طويلة، قم بتشغيل شفاط الأبخرة أو قم بتهوية المكان.
- تراعى بيانات الجهة الصانعة مع الأواني الخاصة. تتعرض رقائق الألومنيوم والأوعية البلاستيكية للانصهار عند وضعها على مواضع الطهي الساخنة.
- ضع الإناء أو المقلاة على منتصف الشعلة. وبذلك يتم نقل حرارة لهب الشعلة بشكل مثالي إلى الجانب السفلي للإناء والمقلاة. ولن يتعرض المقبض أو يد المسك للضرر، وسيتم ضمان توفير الطاقة بدرجة أكبر.
- احرص على أن تظل شعلة الغاز نظيفة وجافة. يجب أن توضع طاسة الشعلة وغطاء الشعلة بشكل مضبوط في موضعها.
- يراعى ألا يتم تشغيل سطح الطهي أبداً والغطاء مغلق، من خلال عبث الأطفال مثلاً.

**⚠ تحذير - خطر من خلال القوة المغناطيسية!**  
توجد قطع مغناطيسية دائمة في نطاق الاستعمال أو في عناصر الاستعمال. هذه القطع يمكن أن تؤثر على الأجهزة الطبية الإلكترونية المزروعة مثل منظم ضربات القلب أو مضخات الأنسولين. إذا كنت حاملاً لأية أجهزة طبية إلكترونية مزروعة التزم بحد أدنى 10 سم كمسافة فاصلة بينك وبين نطاق الاستعمال.

**⚠ تحذير - خطر فرط السخونة!**  
انسداد فتحات التهوية بأرضية الجهاز يمكن أن يتسبب في حدوث سخونة مفرطة. قم دائماً بتثبيت الجهاز على الأرجل الخاصة به.

**⚠ تحذير - خطر الانقلاب!**

**تحذير:** لتجنب خطر انقلاب الجهاز، يجب تركيب وسيلة الاتزان هذه. للتركيب، انظر الإرشادات.

**⚠ تحذير - خطر الصعق الكهربائي!**

- تنطوي أعمال الإصلاح غير السليمة فنياً على أخطار. لا يجوز تنفيذ أعمال الإصلاح وتغيير توصيلات الكهرباء المتضررة إلا بمعرفة فني خدمة عملاء مدرب من قبلنا. إذا كان هناك عطل بالجهاز، فانزع القابس الكهربائي من المقبس أو افصل المصهر الموجود في صندوق المصاهر. اتصل بخدمة العملاء.
- قد تنصهر المادة العازلة لكابلات الأجهزة الكهربائية في حالة ملائمة الأجزاء الساخنة للجهاز. لا تجعل كابلات توصيل الأجهزة الكهربائية تلامس الأجزاء الساخنة للجهاز أبداً.
- الرطوبة التي تتوغل في الجهاز قد تتسبب في حدوث صعق كهربائي. لا تستخدم أية أجهزة تنظيف بالضغط العالي أو أجهزة تنظيف البخار.
- الجهاز المعطل قد يتسبب في حدوث صعق كهربائي. لا تقم أبداً بتشغيل جهاز معطل. انزع القابس الكهربائي من المقبس أو افصل المصهر الموجود في صندوق المصاهر. اتصل بخدمة العملاء.
- يراعى عند تغيير لمبة حيز الطهي أن ملامسات دواة الللمبة يسري فيها تيار كهربائي. قبل تغيير الللمبة، انزع القابس الكهربائي من المقبس أو افصل المصهر الموجود في صندوق المصاهر.

**⚠ تحذير - خطر الإصابة!**

- خدوش زجاج باب الجهاز قد تتطور إلى تشققات. لا تستخدم كاشطة زجاج أو مواد تنظيف خشنة أو مسببة للتآكل.
- تنطوي أعمال الإصلاح غير السليمة فنياً على أخطار. لذا ينبغي تنفيذ أعمال الإصلاح واستبدال وصلات الكهرباء والغاز المتضررة فقط بمعرفة أحد الفنيين المتخصصين المدربين من قبلنا في مراكز خدمة العملاء. إذا كان هناك خلل بالجهاز، فانزع القابس الكهربائي من المقبس أو افصل المصهر الموجود في صندوق المصاهر، وأغلق مصدر الإمداد بالغاز. اتصل بخدمة العملاء.
- تتحرك مفصلات باب الجهاز عند فتح الباب وغلقه وبالتالي يمكن أن ينحشر فيها جزء من جسمك. لا تدخل يدك في نطاق المفصلات.
- وجود اختلالات أو أضرار بالجهاز يعتبر أمراً بالغ الخطورة. لا تقم أبداً بتشغيل جهاز معطل. انزع القابس الكهربائي من المقبس أو افصل المصهر الموجود في صندوق المصاهر. وأغلق مصدر الإمداد بالغاز. اتصل بخدمة العملاء.
- الأواني ذات المقاسات غير المناسبة أو الأواني المتضررة أو التي توضع بشكل غير سليم يمكن أن تتسبب في حدوث إصابات بالغة. تراعى الإرشادات الخاصة بأواني الطهي.
- في حالة وضع الجهاز على قاعدة دون تثبيته، فإنه قد ينزلق منحرفاً عن القاعدة. لذا يجب تثبيت الجهاز مع القاعدة.
- **تنبيه:** قد تنفجر الأغذية الزجاجية أثناء التسخين. أطفئ جميع الشعلات قبل غلق الغطاء. انتظر إلى أن يبرد الفرن قبل غلق الغطاء الزجاجي.
- قبل فتح الغطاء العلوي، قم بإزالة أي بقايا موجودة باستخدام فوطة.



## نقاط عامة

## ⚠ تحذير - خطر الحريق!

- ينشأ تيار هوائي عند فتح باب الجهاز. وقد يحدث تلامس بين ورق إعداد المخبوزات وعناصر التسخين، مما يؤدي إلى اشتعاله. ولا تضع ورق إعداد المخبوزات دون تثبيته على الكماليات أثناء الإحماء. احرص دائماً على تثبيت ورق إعداد المخبوزات في مكانه بوضع طبق أو صينية خبيز عليه. وقم بتغطية السطح المطلوب فقط بورق إعداد المخبوزات. ولا يجوز أن يبرز ورق إعداد المخبوزات فوق الكماليات.
- المواد القابلة للاشتعال التي يتم تخزينها في حيز الطهي يمكن أن تشتعل. لا تحتفظ أبداً بمواد قابلة للاشتعال في حيز الطهي. لا تفتح باب الجهاز أبداً في حالة وجود أدخنة بداخله. أوقف الجهاز وانزع القابس الكهربائي من المقبس أو افصل المصهر في صندوق المصاهر. وأغلق مصدر الإمداد بالغاز.
- الزيوت والدهون الساخنة تشتعل بسرعة. لا تترك الدهون أو الزيوت الساخنة أبداً دون مراقبة. ولا تقم أبداً باستخدام الماء في إطفاء الحريق. وقم بإطفاء موضع الطهي. قم بإطفاء اللهب بحرص باستخدام غطاء أو بطانية لإطفاء الحريق أو ما شابه.
- مواضع الطهي تصبح ساخنة للغاية. لا تضع أبداً أية أشياء قابلة للاشتعال على الموقد. ولا تضع أية أشياء على الموقد.
- يمكن أن يصبح الجهاز ساخناً للغاية، وبالتالي فإن المواد القابلة للاشتعال يمكن أن تشتعل. لا تقم أبداً بتخزين أو استخدام أية أشياء قابلة للاشتعال (على سبيل المثال عبوات الإيروسولات أو مواد التنظيف) أسفل الجهاز أو بالقرب منه مباشرة. ولا تقم بتخزين أية أشياء قابلة للاشتعال داخل الجهاز أو فوقه.
- استخدام مواضع الطهي الغازية دون وضع أواني طهي فوقها يؤدي إلى تولد سخونة شديدة أثناء التشغيل. ويمكن أن يتضرر أو يشتعل الجهاز وشفاط الأبخرة في حالة وجوده فوقه. كما أن بقايا الدهون الموجودة في فلتر شفاط الأبخرة يمكن أن تشتعل. لا تقم بتشغيل مواضع الطهي الغازية إلا مع وضع أواني طهي عليها.
- يصبح ظهر الجهاز ساخناً للغاية. وقد يؤدي ذلك إلى الإضرار بأسلاك التوصيل. ویراعی أنه لا يجوز أن تلامس وصلات التيار الكهربائي والغاز ظهر الجهاز.

## ⚠ تحذير - خطر الإصابة بحروق!

- يصبح الجهاز ساخناً للغاية. لا تلمس أبداً الأسطح الداخلية لحيز الطهي أو عناصر التسخين وهي ساخنة. احرص دائماً على ترك الجهاز يبرد. وأبعد الأطفال عن الجهاز.
- الكماليات وأواني الفرن تصبح ساخنة للغاية. استخدم دائماً فوطة للفرن لإخراج الكماليات أو أواني الفرن من حيز الطهي.
- أبخرة الكحول يمكن أن تشتعل في حيز الطهي وهو ساخن. لا تقم أبداً بتحضير أطعمة تحتوي على كميات كبيرة من السوائل المشتعلة على نسبة عالية من الكحول. اقتصر على استخدام كميات قليلة من المشروبات المركزة. افتح باب الجهاز بحرص.
- تصبح مواضع الطهي والمنطقة المحيطة بها ساخنة للغاية، خصوصاً إطار الموقد في حال وجوده. لا تلمس الأسطح الساخنة أبداً. وأبعد الأطفال عن الجهاز.
- الأجزاء التي يمكن الوصول إليها تسخن أثناء التشغيل. لا تلمس أبداً الأجزاء الساخنة. وأبعد الأطفال عن الجهاز.
- أواني الطهي الفارغة تسخن بشدة عند وضعها على مواضع الطهي الغازية المشغلة. لا تقم أبداً بتسخين أواني طهي فارغة.
- ⚠ تحذير - خطر الإصابة بحروق!
- الأجزاء التي يمكن الوصول إليها تسخن أثناء التشغيل. لا تلمس أبداً الأجزاء الساخنة. وأبعد الأطفال عن الجهاز.
- قد يتسرب البخار الساخن عند فتح باب الجهاز. افتح باب الجهاز بحرص. وأبعد الأطفال عن الجهاز.
- وجود بعض الماء في حيز الطهي وهو ساخن يمكن أن يولد بخار ماء ساخن. لا تقم أبداً بصب الماء في حيز الطهي الساخن.

## الاستعمال المطابق للتعليمات

اقرأ هذا الدليل بعناية. عندئذ فقط سيمكنك استخدام الجهاز بشكل صحيح وآمن. احتفظ بدليل الاستعمال والتركيب لاستخدامه لاحقاً أو لتسليمه للمالك الجديد.

افحص الجهاز بعد إخراجهِ من مواد التغليف. ولا تقم بتوصيل الجهاز في حالة وجود أضرار ناتجة عن عملية النقل.

لا يجوز توصيل الأجهزة بدون قوابس إلا من قبل فني معتمد. حيث لا يحق المطالبة بحقوق الضمان في حالة الأضرار الناتجة عن التوصيل الخاطئ.

هذا الجهاز مخصص للاستخدام المنزلي وفي النطاق الداخلي فقط. اقتصر على استخدام الجهاز في إعداد الأطعمة والمشروبات. ويتعين مراقبة الجهاز أثناء التشغيل. استخدم هذا الجهاز في الأماكن المغلقة فقط.

هذا الجهاز مناسب للاستخدام على ارتفاع حتى 2000 متر فوق مستوى سطح البحر كحد أقصى.

هذا الجهاز ليس مصمماً للتشغيل مع ميقاتي خارجي أو بواسطة جهاز تشغيل عن بعد.

لا تستخدم شبكة حماية أطفال أو تجهيزات حماية غير مناسبة. فقد تؤدي إلى وقوع حوادث.

يمكن استخدام هذا الجهاز من قبل الأطفال من عمر 8 سنوات أو الأشخاص الذين يعانون من نقص في القدرات الجسدية أو الحسية أو العقلية أو الأشخاص الذين لديهم قصور في الخبرة أو المعرفة شريطة أن يقوم شخص مسؤول عن سلامتهم بالإشراف عليهم أو توجيههم إلى كيفية الاستخدام الآمن للجهاز مع التأكد من إدراكهم للأخطار المرتبطة بذلك.

لا يجوز للأطفال العبث بالجهاز. لا يجوز للأطفال تنظيف الجهاز أو إجراء أعمال الصيانة الممنوعة بالمستخدم ما لم يكونوا في سن 15 سنة أو أكثر، على أن يتم مراقبتهم أثناء ذلك.

الأطفال دون سن 8 سنوات يجب إبعادهم عن الجهاز وكابل التوصيل.

احرص دائماً على إدخال الكماليات في حيز الطهي بشكل صحيح. ← «الكماليات» في صفحة 12

أغلق صمام الأمان الموجود بوصلة إمداد الغاز إذا كان من المقرر عدم تشغيل الجهاز لفترة طويلة.

## إرشادات الأمان المهمة

**⚠ تحذير - التصرف في حالة شم رائحة غاز!**  
الغاز المتسرب يمكن أن يؤدي إلى حدوث انفجار.

**في حالة شم رائحة غاز أو حدوث اختلالات عند التوصيل بالغاز:**

- أغلق مصدر الإمداد بالغاز أو صمام أسطوانة الغاز على الفور.
- قم على الفور بإطفاء مصادر اللهب المكشوف والسجائر.
- لا تقم بتشغيل مفاتيح الأضواء أو الأجهزة، ولا تسحب أي قابس من أي مقبس. ولا تستخدم الهاتف الثابت أو الجوال داخل المنزل.
- افتح النوافذ وقم بتهوية المكان جيداً.
- اتصل بمركز خدمة العملاء أو شركة الإمداد بالغاز.

### ⚠ تحذير - خطر الاختناق!

يراعى أن استخدام موقد غاز يؤدي إلى توليد حرارة ورطوبة ونواتج قابلة للاحتراق في المكان الموجود فيه. تحقق من التهوية الجيدة لمكان التركيب. واحرص على أن تكون فتحات التهوية الطبيعية مفتوحة أو قم بتوفير تجهيزات تهوية آلية (على سبيل المثال شفاط أبخرة). في حالة استخدام الجهاز بشكل مكثف لفترات طويلة، فإن ذلك قد يتطلب توافر تهوية إضافية، على سبيل المثال فتح أحد النوافذ أو توافر تهوية أكثر فعالية، على سبيل المثال تشغيل تجهيزات التهوية الآلية الموجودة على درجة قدرة أكبر.

## فهرس المحتويات

|    |                                                    |   |
|----|----------------------------------------------------|---|
| 21 | الاختلالات، ما العمل؟                              | ? |
| 21 | تغيير لمبة الفرن                                   |   |
| 22 | خدمة العملاء                                       |   |
| 23 | الأطباق التي تم اختبارها في ستوديو الطهي الخاص بنا |   |
| 23 | جدول الأطباق                                       |   |
| 24 | نصائح الاستخدام                                    |   |

تجد المزيد من المعلومات حول المنتجات والكماليات وقطع الغيار والخدمات على موقع الإنترنت: [www.bosch-home.com](http://www.bosch-home.com) وفي المتجر الإلكتروني على موقع الإنترنت: [www.bosch-eshop.com](http://www.bosch-eshop.com)

يسر فريق استعلامات بوش أن يقدم لك المشورة ومعلومات المنتجات اللازمة والرد على استفساراتكم فيما يتعلق بتطبيقات واستخدامات الأجهزة على رقم هاتف: 089 69 339 339 (وذلك من الاثنين إلى الجمعة: من الساعة 8.00 إلى الساعة 18.00) يسري فقط على ألمانيا.

|    |                                          |  |
|----|------------------------------------------|--|
| 4  | الاستعمال المطابق للتعليمات              |  |
| 4  | إرشادات الأمان المهمة                    |  |
| 5  | نقاط عامة                                |  |
| 7  | أسباب الأضرار                            |  |
| 7  | الموقد                                   |  |
| 8  | الفرن                                    |  |
| 8  | حماية البيئة                             |  |
| 8  | توفير الطاقة عند استخدام الفرن           |  |
| 8  | توفير الطاقة عند استخدام الموقد          |  |
| 8  | التخلص من المخلفات بطريقة لا تضر بالبيئة |  |
| 9  | التعرف على الجهاز                        |  |
| 9  | لوحة الاستعمال                           |  |
| 10 | الساعة الإلكترونية                       |  |
| 10 | سطح الموقد                               |  |
| 11 | الفرن                                    |  |
| 11 | مروحة التبريد                            |  |
| 11 | درج الحفظ                                |  |
| 12 | الكماليات                                |  |
| 12 | وظيفة التثبيت                            |  |
| 13 | الكماليات الخاصة                         |  |
| 13 | قبل الاستخدام لأول مرة                   |  |
| 13 | ضبط الوقت                                |  |
| 13 | تسخين الفرن                              |  |
| 14 | تنظيف أغطية وطاسات الشعلات               |  |
| 14 | تنظيف الكماليات                          |  |
| 14 | تركيب الجلب الملولة للسخن الدوار         |  |
| 14 | تركيب طقم الحوامل التلسكوبية             |  |
| 14 | استعمال الجهاز                           |  |
| 14 | الموقد                                   |  |
| 15 | الفرن                                    |  |
| 15 | السخن الدوار                             |  |
| 15 | قواطف                                    |  |
| 17 | المنظفات                                 |  |
| 17 | المنظفات المناسبة                        |  |
| 18 | أسطح حيز الطهي                           |  |
| 18 | المحافظة على نظافة الجهاز                |  |
| 18 | تنظيف حيز الطهي                          |  |
| 19 | القضبان                                  |  |
| 19 | فك شبكات قضبان التعليق                   |  |
| 19 | تركيب شبكات قضبان التعليق                |  |
| 19 | باب الجهاز                               |  |
| 19 | فك وتركيب زجاج الباب                     |  |
| 20 | فك وتركيب باب الجهاز                     |  |





## Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- **Expert tips & tricks for your appliance**
- **Warranty extension options**
- **Discounts for accessories & spare-parts**
- **Digital manual and all appliance data at hand**
- **Easy access to Bosch Home Appliances Service**

Free and easy registration – also on mobile phones:

**[www.bosch-home.com/welcome](http://www.bosch-home.com/welcome)**



## Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, need help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you:

**[www.bosch-home.com/service](http://www.bosch-home.com/service)**

**Contact data of all countries are listed in the attached service directory.**

### **BSH Hausgeräte GmbH**

Carl-Wery-Straße 34  
81739 München, GERMANY  
[www.bosch-home.com](http://www.bosch-home.com)

A Bosch Company



9001160912  
020809

Valid within Great Britain:  
Imported to Great Britain by  
BSH Home Appliances Ltd.  
Grand Union House  
Old Wolverton Road  
Wolverton, Milton Keynes  
MK12 5PT  
United Kingdom